

DESIGN OF STEEL STRUCTURES

- 1) Introduction
- 2) General Design Consideration
- 3) Connection
- 4) Tension Member
- 5) Comp. Member
- 6) Beam
- 7) Wanhry Girder
- 8) plate girder
- 9) Industrial building.

INTRODUCTION

IS codes

IS 800 : 2007 → General construction in steel
(With abendment no.1, ^{Tanuray} ~~generally~~ 2012)

IS 808 : 1989 → Dimensions for steel sections
(Steel Tables)

Steel :- It is an alloy of Iron having carbon content
| b/w 0.1 - 0.1%

• Based on carbon content, 3 types of steel.

- ✓ ① Low carbon steel → (0.1 - 0.25%) carbon.
- ② Medium carbon steel → (0.25 - 0.60%)
- ③ High carbon steel → (0.6 - 1.1%)

Deoxidisers. Such as silicon or Aluminium are used to control dissolved oxygen during the Manufacturing process

• lower % of oxygen content is good for durability of steel and on the Basis of oxygen content we classify steel as
(Air in voids will be less)

- ✓ (i) Killed steel → (< 30 ppm oxygen)
- (ii) Semi-killed → (30 - 150 ppm)
- (iii) Rimmed steel → (> 150 ppm oxygen)

Structural steel are generally killed or semi-killed.
Carbon % in structural steel is generally < 0.25%.
(Low carbon steel) → Ductility ↑

Mild steel has a carbon content of nearly 0.1%.

IS 800:2007 can be used for structural mild steel or High Tension structural steel.

Various Grades of steel :-

Grade	ultimate stress (Mpa)	yield stress (Mpa)
✓ E 250 (Fe 410) A	410	250
B	410	250
C	410	250
E 300 (Fe 440)	440	300
E 350 (Fe 490)	490	350
E 410 (Fe 540)	540	410

E 250 (Fe 410) A → Grade of steel

char. yield stress

char. ultimate stress


Fe 410 W → Weldability Higher

char. ultimate stress

NOTE

- ① structural steel is specified according to characteristic ultimate Tensile stress i.e. f_u
It is the ultimate stress below which not more than 5% of the materials are expected to fail.

- ② RIF Bars in RCC are specified according to yield stress



- ③ Thinner the secⁿ, Higher is the strength due to Higher amount of rolling, cold working, uniform rate of cooling etc.

Ex.	$t < 20 \text{ mm}$	$20 < t < 40 \text{ mm}$	$t > 40 \text{ mm}$
E 250 (Fe 410)	$f_y = 250 \text{ MPa}$	240 MPa	230 MPa
$t \rightarrow$ 5mm, Rolling width, strength $\rightarrow$ 6mm			

- ④ Brittle fracture occurs due to higher Tensile Stress, lower temp., thicker material, Rapid change of stresses etc.
- ⑤ Stainless steel is low carbon steel with around 10.5% chromium by weight. strain $\rightarrow$ 5%, Ductility $\uparrow$, corrosion $\downarrow$
- Grade A is used for Non-critical applications i.e. When members are not prone to brittle fracture. ^{Normal} structure
- Grade B is used for critical applications When Temp. doesn't fall below 0°C and When parts are prone to Brittle fracture or Fluctuations of stresses as in case of Bridges
- Grade C has a Guaranteed low temp. upto -40°C and it shall be used for impact loading and higher chances of Brittle fracture Ex. Ship, sea, Marine
- Physical properties of steel (for all Grades)

- ① Density of steel $\rightarrow \rho = 7850 \text{ kg/m}^3$
- ② Modulus of Elasticity $\rightarrow 2 \times 10^5 \text{ MPa}$
- ③ Poisson's Ratio $\rightarrow \mu = 0.3 \rightarrow \text{Elastic Zone}$
 $\mu = 0.5 \rightarrow \text{plastic zone}$
- ④ Shear Modulus $\rightarrow G = \frac{E}{2(1+\mu)} = 0.769 \times 10^5 \text{ MPa}$ (Elastic zone)
- ⑤ Specific Gravity $\rightarrow 7.85$
- ⑥ Coefficient of Thermal expansion $\rightarrow \alpha = 12 \times 10^{-6} / ^\circ\text{C}$



* Advantage of Steel as a Structural Material

- ① High strength per unit weight
- ② High Ductility, High toughness
- ③ uniformity i.e. very less quality control issues
- ④ Environment friendly, can be 100% recycled
- ⑤ Easy connections and faster constructions
- ⑥ Easy repair and modifications
- ⑦ longer life is properly maintained.

* Disadvantages

- ① Higher maintenance due to corrosion
- ② Fire proofing cost
- ③ prone to buckling due to longer and slender member
- ④ fatigue (can't use more than 50% strength)


Aluminium



- Higher strength to unit wt. Ratio compare to steel
- However due to lower Modulus ($1/3^{\text{rd}}$ of steel) Bigger secⁿ are required to avoid buckling
- Greater Resistance to corrosion and hence less maintenance
- Density $\approx 1/3^{\text{rd}}$ of steel. ($2700-2800 \text{ kg/m}^3$)
- Coefficient of thermal expansion $\approx 2 \times \text{steel} = 23 \times 10^{-6} / ^\circ\text{C}$
- less Ductile than Mild steel
- Doesn't have a well defined yield point and hence yield is assumed @ 0.2% proof strain $\rightarrow$ (stress) corresponding
- As it's Modulus is $1/3^{\text{rd}}$ of steel, it can absorb 3 times the energy @ same stress level compare to steel member of same dimension provided the stress doesn't exceed the proportionality limit, Hence also used for impact loading provided Higher Deflection is allowed.

• Design concept same as steel structure.

Standardised structural steel sections:-



ISJB $\rightarrow$ Indian standard junior Beam


ISLB $\rightarrow$ IS Light Beam

ISMB $\rightarrow$ IS Medium Beam

ISHB $\rightarrow$ IS Heavy Beam

ISSC $\rightarrow$ IS column section (Type of I section)

Ex: ISMB 300 $\rightarrow D = 300 \text{ mm}$, $B/b_f = 140 \text{ mm}$
 $t_f = 13.1 \text{ mm}$, $t_w = 7.7 \text{ mm}$




ISJC $\rightarrow$ Junior channel

ISLC $\rightarrow$ light channel

ISMC $\rightarrow$ medium channel

Ex: ISMC 100 $\rightarrow D = 100 \text{ mm}$, $B = 50 \text{ mm}$
 $t_f = 7.7 \text{ mm}$, $t_w = 5 \text{ mm}$


Angle secⁿ



ISA $\rightarrow$ Is equal / unequal Angle

ISA $\rightarrow$ 100 x 80 x 8

T-secⁿ



ISNT $\rightarrow$ Normal T-section

ISMT $\rightarrow$ Medium T-section

Ex: ISNT 150 @ 223.7 N/m

ISRD $\rightarrow$ Round Bars

Ex: ISRD 10 (dia = 10 mm)

ISSQ $\rightarrow$ Square Bars

Ex: ISSQ 10 (10 mm = side)

ISPL $\rightarrow$ plate


Ex: ISPL 2000 x 1000 x 8 (l x b x t)

ISFI $\rightarrow$ Flat secⁿ


Ex: 30 ISFI 10 $\rightarrow$ (30 mm $\rightarrow$ width, 10 mm $\rightarrow$ thickness)

These secⁿ can be used either alone (Rolled secⁿ) or in combinations (built up secⁿ)

Convention for Member Axes :-



along length $\rightarrow$ $x-x$
parallel to flange $\rightarrow$ $Z-Z$ (Major)
 $\perp$ to flange $\rightarrow$ $Y-Y$ (Minor Axis)



parallel to smaller leg $\rightarrow$ $Z-Z$ (higher inertia)
 $\perp$ to smaller leg $\rightarrow$ $Y-Y$ (lesser inertia)
in Earlier version of the IS code i.e IS 800 1984
Major Axis was denoted as $x-x$

GENERAL DESIGN consideration

Structure shall fulfill safety, serviceability, Economy, Aesthetic and environmental criteria.

3. Design Methods :-


- (i) Elastic / WSM
- (ii) plastic / ULM
- (iii) LSM

(i) WSM

It assumes linear elastic Response and safety is ensured by ensuring working stress to be less than permissible stress.

$$(\text{Strength of Material} / FOS) = f_y / FOS$$

However assumptions of stress being less than permissible stress is not realistic because of stress concentration, and long term effect of creep & shrinkage, Residual stress and other secondary stresses.



Flange की length बढ़ाई जाती है, Web की कम due to comp. in web

- Unequal Rate of cooling due to diff^r thickness and exposed area and uneven comp. by roller will lead to generation of residual stress. The part of secⁿ which cools first will have comp. because it will resist the shortening of slower cooling part. Also the slower cooling part will have Tension
- Does not utilise the reserve strength derived from ductility and redistribution of stress and hence FOS doesnot give a realistic figure or exact Margin of safety
- FOS doesnot have a scientific Basis and is based on experience.
- It fails to discriminate b/w diff^r types of load that are simultaneously acting but have varying degree of uncertainty.



② ULM or load Factor Method

Design is done as in the case of plastic analysis in which working load multiplied by load factor is ensured to be less than the collapse load or ultimate load. However this Method doesnot consider serviceability condⁿ like deflection, vibration etc

Also structure subjected to impact and Fatigue loading shall not be design with plastic theory, As it uses full material strength beyond elastic limit

- Also safety for material is not considered Hence this gives smaller c/s than WSM.

② LSM:-





$$C = T = f_y \cdot \frac{bD}{2}$$

$$MOR = f_y \cdot \frac{bD^2}{4} = f_y \cdot Z_p$$


$$M_e = f_y \cdot Z_e = f_y \cdot \frac{bd^2}{6}$$

$Z_e \rightarrow$ elastic Modulus
 $Z_p \rightarrow$ Plastic Modulus



$$M_p = f_y \cdot \frac{bd^2}{4}$$

$$\frac{W_1 l^2}{12} = M_p \quad (\text{Hinge @ ends})$$



$$\frac{W_2 l^2}{8} = \frac{M_p}{2}$$

$$\Rightarrow \boxed{W_1 + W_2 = \frac{16 M_p}{l^2}}$$

③ LSM:- To avoid all deficiencies of WSM & plastic Method, LSM was proposed. partial safety factors are used for load and material strength both based on acceptable probability of failure derived using reliability analysis (level 1)

- partial safety factor takes into account possible overload and understrength.

Design action
(considering partial safety factor for loads)

$\leq$

Design strength
(considering partial safety factor for Material)

• Factored load / Design load = characteristic load $\times \gamma_f$
(f_d)

$\gamma_f \rightarrow$ partial safety factors for loads depending on loads combination and limit state being considered.

• Design strength (f_d) = $\frac{\text{characteristic strength}}{\gamma_m}$

$\gamma_m \rightarrow$ partial safety factor for material strength.

* characteristic load is the load which has 95% probability of not being exceeded during the life of the structure.

* characteristic strength is the strength below which not more than 5% of test samples are expected to fall.

γ_f accounts for ($\gamma_f \rightarrow$ partial safety for loads)

- (i) possibility of load exceeding characteristic load
- (ii) possibility of inaccurate assessment of load
- (iii) Uncertainty in assessment of effect of load.
- (iv) Uncertainty in the assessment of limit state being considered

γ_m accounts for ($\gamma_m \rightarrow$ partial safety factor for Material)

- (i) possibility of strength falling below characteristic strength
- (ii) Reduction in Member size due to faulty construction
- (iii) Reduction in strength due to fabrication & Tolerances.

(joint match जॉइंट मॅच)

(iv) uncertainty in theoretical assumptions.

(v) uncertainty in the calculation of strength of Member

Limit states are the states beyond which the structure becomes unfit for use.

The limit states are classified as —

1) limit state of strength / ultimate limit state

2) limit state of serviceability

Limit state considered by IS code.

① Limit state of strength

1) strength including yielding, buckling and transformation into a mechanism (plastic hinge formation)

2) stability against overturning and sway

3) failure due to excessive deformation or Rupture

4) Fracture due to fatigue

5) Brittle fracture.

② Limit state of serviceability

(i) deformation & deflection (can cause damage to non-structural component and finishes but not to structural component)

2) vibration (causing discomfort)

3) repairable damage or crack due to fatigue

4) corrosion, durability

5) Fire resistance

Limit state method consider safety @ ultimate load and serviceability @ working load.

NOTE In practice structures are designed for critical state and check for other state. However in most of cases ultimate limit state governs the design.

partial safety factor for material (γ_m)

Defination

γ_m

- (i) Resistance Governed by yielding (γ_{mo}) 1.10
- (ii) Resistance Governed by buckling (γ_{mb}) 1.10
- (iii) Resistance Governed by ultimate stress (γ_{ms}) 1.25

for connections

shop fabrication



field fabrication

Bolt-Bearing type (γ_{mb})	1.25	1.25
Bolts-Friction type (γ_{mf})	1.25	1.25
Rivets (γ_{mr})	1.25	1.25
Welds (γ_{mw})	1.25	1.5

We generally consider Rupture in Net Area and yielding in Gross secⁿ

Yielding is not considered @ Net secⁿ i.e @ joint location as some yielding @ joint is allowed.



Basically We need to check excessive deformation and Rupture



$$\text{Area} = (B - d_o) t$$


$$\sigma = \frac{T}{\text{Area}} = \frac{T}{(B - d_o) t}$$

← NM 375C bolt, hole में खाई है.



375C Hole, bolt में खाई है
— Shear में Force transfer

Rivet



Partial safety factor for Load (γ_f)

Combination	Limit state of strength					Limit state of serviceability			
	D.L	L.L	E.O/W.L	A.L		D.L	L.L	E.O/W.L	
		Leading	Accom.				Leading	Accom.	
DL+LL+CL	1.5	1.5	1.05	—	—	1	1	1	—
DL+LL+CL	1.2	1.2	0.53	1.2	—	1	0.8	0.8	0.8
DL+LL+CL + E.O/W.L	1.2	1.2	1.05	0.6	—	1.0	0.8	0.8	0.8
DL+EQ/WL	1.5 or 0.9	—	—	1.5	—	1	—	—	1
DL+ER	1.2 or 0.9	1.2	—	—	—	No serviceability check required			
DL+LL+AL	1.0	0.35	0.35	—	—				

C.L → crane load

A.L → Accidental load

ER → Erection load

NOTE

0.9 value shall be considered when stability against overturning, sliding or stress reversal is critical

- Leading live load is the live load causing the higher load effects and accompanying L.L is the L.L except leading L.L i.e. load causing lower effects.
- Impact, collisions, fire etc can be called as Accidental load.
- Wind load and EQ load are not considered simultaneously.
- Although fatigue failure is usually considered as Ultimate limit state, fatigue failure design is carried out @ Working load because in case of fatigue load applied is normal load or characteristic load with higher no. of repetitions.

The characteristic load require statistical data in the absence of which the load can be considered from different IS code.

IS 875 (part-1) → D.L

(part-2) → L.L


(part-3) → W.L

(part-4) → snow load

(part-5) → Erection load.

IS 1893 (part-1) → EQ load

Que.



Find the design comp. and tensile force for the principle Rafter.

Member	DL (kN)	LL (kN)	WL (kN)
$L_0 U_1$	-9.5	-9.5	32.5
$U_1 U_2$	-8.0	-8.0	32.5
$U_2 U_3$	-8.0	-8.0	32.5
$U_3 L_3$	-9.5	-9.5	32.5

Member	$1.5(DL+LL)$	$0.9 DL + 1.5 WL$	$1.2 (DL+LL+WL)$
$L_0 U_1$	-28.5	40.2	16.2
$U_1 U_2$	-24	41.5	19.8
$U_2 U_3$	-24	41.5	19.8
$U_3 L_3$	-28.5	40.2	16.2

Design comp. force = -28.5 kN

Design Tensile force = 41.5

Ans

Permissible stress
 Axial Tension/comp. = $0.6 f_y$
 Bending Tension/comp. = $0.66 f_y$
 in shear = $0.4 f_y$
 in Bearing = $0.75 f_y$

WSM

LSM $\rightarrow \frac{f_y}{1.1} \rightarrow$ All
 $\frac{f_y}{\sqrt{3} \times 1.1} \rightarrow$ Shearing.
 $\frac{f_y}{\sqrt{3} \times 1.25} \rightarrow$ Bolt or Weld

} Structure

BOITED CONNECTIONS

Depending upon Rigidity of joint connections are classified as:-

① Rigid connection / Moment connection :-

Develop the full or significant Moment capacity of connecting Members and retain the original angle b/w the members


② Simple / flexible connection

No moment transfer is considered b/w the connected parts and hence joints are assumed to be pin or hinge connection

③ Semi-Rigid connection

Does not have sufficient Rigidity to hold the original Angle b/w the members and develop less than full Moment capacity of the connected Members.

NOTE In Reality all the connections are Semi-Rigid. However for convenience We assume either Rigid or simple Conne.




Also connections can be classified as -

A) Direct connection


B) Eccentric connection.

if the resultant load passes through the C.G. of connection $\rightarrow$ Direct connection

If the resultant load does not pass through the C.G. of connection $\rightarrow$ Eccentric connection.




Direct connection.



Direct shear + Twisting Moment

Eccentric connection





Direct shear + BM

Eccentric



Various type of connections —

- ① Rivet
- ② Bolted
- ③ Welded

Rivet



Rivets are inserted in the hole made to join the member
Hammering is done to make head on the other side



The Nominal dia of Rivet is the shank dia
under cold temp. and the Gross Dia of Rivet is
taken as the Dia of Hole.

It is assumed that during Hammering action
the Rivet hole is completely filled with the
material so from strength calculation point of view
Diameter of Rivet is taken as Diameter of Hole.
and it is called Gross Dia of Rivet

for ease in construction, rivet holes are generally
made larger than the shank dia.

$$\text{Gross Diameter} = \text{Dia of hole } (d_0) = d + 1.5 \text{ mm} \quad (d \leq 25 \text{ mm})$$


$$= d + 2 \text{ mm} \quad (d > 25 \text{ mm})$$

$d \rightarrow$ nominal dia of Rivet

All formulas of Bearing type bolt are applicable for Rivets.


Rivets are good for Fatigue loading, alternate stress, Dynamic loading, impact loading etc.

Bolted connection



$A_{sb} \rightarrow$ shank dia of bolt

$A_{nb} \rightarrow$ Net area of bolt



Type of Bolt


- ① Black bolt / unfinished / ordinary / Rough / common Bolt
- ② Turned bolt / close Tolerance Bolt
- ③ High strength Bolt [can be HSF61 Type or Bearing Type]

① Black Bolts :- These are primarily used in light structures under static load such as small Trusses, purlins etc. Also used as Temporary Fasteners during erection.

- Least expansive bolts with high tolerance, However
- it may not produce the least expansive connection.
- Not recommended for connections subjected to impact, fatigue or dynamic load.

② Turned-Bolts :- Has less tolerance allowed than Black. These Bolts are used when accurate Alignment of components is there.

③ High strength Bolts :-



High strength bolts are less Ductile than ordinary.

Bolts may be tighten until High Tensile stress is developed so that the connected parts are clamped together tightly.

permits the load to be primarily transfer by friction



- Due to the friction the slip in the joint is eliminated and Hence the joints with HSFb Bolts are called non-slip connection. The coefficient of friction is called slip factor and the induced initial tension is called proof load.

- Better for Bridges, seismic loading, fatigue etc.
- These Bolts can replace riveted connection.


Bearing Type connection (Direct / simple connection)

Two Types of joint


- ① Lap joint
- ② Butt joint





single bolted lap joint



Double bolted lap joint




Single cover Single bolted butt joint




Double bolted Double cover Butt joint

Due to eccentricity in load in lap joint and single cover and butt joint bending will be generated and hence bolts may fail in tension. To minimise this effect at least two bolts in a line shall be provided in a lap joint.

- Eccentricity of load is eliminated in Double cover Butt joint and hence this type of joints are preferred.



$$A_n = (B - 2d_o)t$$



$$A = (B - d_o)t$$

In case of Tension, Net Area is effective






In case of Compression, Gross Area is effective provided

All holes are filled, if Holes are unfilled, Area corresponding to that must be subtracted to get the eff. Area in compression.

Load Transfer Mechanism :-


- ① In Bearing type connection → By shearing & Bearing
- ② In Friction type connection → By Friction.

In lap joint



single shear plane

In double cover single bolted Butt joint



- Single shear plane in case of lap joint and single cover Butt joint
- Double shear plane in case of Double cover butt joint.
- Shear capacity of a bolt in double cover bolt joint is higher than that of a bolt in lap joint

NOTE . Bolts are designated as M16, M20, M18 (5-36 mm)
• Bolts of property class (3.6 - 12.4) are available

M20 bolt of property class 4.6


$d = 20 \text{ mm}$

$f_{ub} = 400 \text{ MPa}$, $f_{yb} = 400 \times 0.6 = 240 \text{ MPa}$

Normally we use 4.6 and 8.8


Assumptions in Bolted connection (Bearing Type):-

- ① friction b/w the plates is Neglected and load is resisted by bolts in shearing and Bearing.
- ② shear stress is uniform over the c/s of the Bolt
- ③ Distribution of stress in the plate b/w the bolt hole is uniform i.e stress concentration is Neglected



The above assumption is not valid @ working load condition. However @ ultimate load due to High Ductility of steel, redistribution of stress will be there and uniform stress distribution may be assumed.

- ④ Bolts in a Group Subjected to direct load share the load equally i.e Bolts are equally stressed.
(Assuming Same Dia bolts)




NOTE For short length of joint, the forces in bolt will be redistributed by plastic Action and hence the bolt will share the shear force equally,

However in a long joint, the shear force is not evenly distributed among the bolts and the bolts at the ends of a joint resist the highest amount of SF. This may lead to progressive joint failure called UnButtnering effect. To account for this IS code recommends reducing in the shearing capacity of bolts for long joints.

However in ∞ rigid plate the stress in all bolts will be same even in the elastic condition.

⑤ Bending stress developed in Hole is Neglected.



if the Grip length is more correction factor is introduced to reduce the shear stress

permissible

⑥ Bearing stress is assumed to be uniform over the Nominal contact Area b/w the plate and the Bolt.




$d \rightarrow$ Nominal dia of bolt


- ⑦ if Nothing is specified then the area for resisting single shear shall normally be taken as the area of root of thread (A_{nb})
for Double shear, take one shear plane at Shank area and other @ root of thread.

Failure of bolted connections


(i) Shear failure of bolt :-




(ii) shear failure of plates




(iii) Bearing failure of bolts




(iv) Bearing failure of plates




(V) Tension failure of bolts:-



(Vi) Tension failure of plate / Tearing of plate / Rupture of plate



(vii) Block shear failure:-



Codal Recommendations:-

1) Dia of bolt hole

Dia of bolt $\leq 14 \text{ mm}$ $16 \text{ to } 24 \text{ mm}$ $> 24 \text{ mm}$
(d)

Dia of ~~bolt~~ ^{hole} $(d+1) \text{ mm}$ $(d+2) \text{ mm}$ $(d+3) \text{ mm}$
(d₀)



NOTE • Under Normal situation i.e No dynamic loading
Dia of bolt hole is made larger than bolt dia
to facilitate erection and to allow for inaccuracies
in fabrication.

• oversize holes and slotted holes are used in
friction type or slip resistance connection


2) pitch (P):-

c/c distance b/w individual bolts in a line
in the dirⁿ of load

Distance b/w any two consecutive bolts in a
zig-zag pattern of bolts measured parallel to the
dirⁿ of load is called staggered pitch




NOTE




For wide plate pitch is also defined as c/c distance of bolts measured along the length of the member or the connection. When per pitch strength is given, it is in the transverse dirⁿ of the load.

gauge (g) :-



The spacing b/w adjacent parallel line or bolt transverse to the dirⁿ of load is called Gauge.

The distance b/w the back of the rolled section and the first bolt lying is also called gauge.



Min. pitch and Gauge


$$\text{min. pitch and Gauge} = 2.5 \times d$$

$d \rightarrow$ nominal dia of bolt

- To avoid overlapping
- To place washer
- To give space for Machine

Max. pitch

- (i) for Tension member $p \geq \text{Min. } (16t, 200 \text{ mm})$
- (ii) for compression member $p \geq \text{Min. } (12t, 200 \text{ mm})$
 $\Rightarrow$ chances of Buckling, Hence it is less
- (iii) for lines near the edge $p \geq \text{Min. } \begin{cases} 4t + 100 \text{ mm} \\ 200 \text{ mm} \end{cases}$




- (iv) for Staggered bolts, when gauge doesn't exceed 75 mm, the above distances specified in (i), (ii) & (iii) can be increased by 50%

- Max. Gauge $g \geq^{\text{min}} (32t, 300 \text{ mm})$

t in all above cases $\rightarrow$ Thickness of thinner plate

③ End and Edge Distance

- End distance is the distance in the dirⁿ of stress from the center of the hole to the end of the element
- Edge distance is at Right angle to the stress.
- Bolt hole should not placed very close to the edge to avoid failure in shearing, bearing and to provide space for bolt head, washer nut etc.




Also Max^m Edge distance is limited to reduce the chances of corrosion due to moisture.

$$\begin{aligned} \text{Min Edge / End distance} &= \underline{1.7 d_o} \text{ for sheared / hand flame cut edges} \\ &= \underline{1.5 d_o} \text{ for rolled or Machine Flame cut plane edges} \end{aligned}$$

$$\begin{aligned} \text{Max. Edge / End distance} &= \underline{12 t \epsilon} \\ t \rightarrow \text{thinner plate (mm)} \end{aligned} \quad \left\{ \begin{array}{l} \epsilon = \sqrt{\frac{250}{f_y}} \end{array} \right.$$

When the members are exposed to corrosive environment the Max. edge distance $\nless 40 \text{ mm} + 4t$

4) Tacking bolt



- The purpose of tacking bolt or stick is to equalize the stress in the two components, and to ensure that two components behave as one unit
- in comp. Member it also reduces chances of Buckling
- Tacking bolts aren't subjected to calculate stress.

(i) In General, Max. pitch = $\min \left\{ \begin{array}{l} 32t \\ 300 \text{ mm} \end{array} \right.$

When connection is not exposed to weather

$$= \min \left\{ \begin{array}{l} 16t \\ 200 \text{ mm} \end{array} \right.$$

When connection is exposed to weather

(ii) For two members placed back to back
Max. pitch of lacing bolt should not exceed
1000 mm for Tension Member and 600 mm for Compression member

Bearing type connection


$$\text{Strength of bolt / Bolt Value } (V_{db}) = \min. \left\{ \begin{array}{l} \text{shearing strength of bolt } (V_{dsb}) \\ \text{Bearing strength of bolt } (V_{dph}) \end{array} \right.$$

① Shearing strength of Bolt

$$V_{dsb} = \frac{V_{nsb}}{\gamma_{mb}}$$

V_{nsb} → nominal shearing strength of bolt

γ_{mb} → partial safety factor for material, bearing type bolt (1.25)



$$V_{dsb} = \frac{f_{ub}}{\sqrt{3} \gamma_{mb}} [n_n A_{nb} + n_s A_{sb}] \times \beta_{tj} \times \beta_{lg} \times \beta_{pk}$$

f_{ub} → ultimate tensile strength of bolt

A_{nb} → net shear area of bolt @ thread

A_{sb} → nominal shank area of bolt $\left(\frac{\pi}{4} d^2\right)$

n_n → no. of shear plane through thread

n_s → no. of shear plane through shank

for single shear plane $n_n=1$, $n_s=0$

for Double shear plane $n_n=1$, $n_s=1$


β_{lj} , β_{lg} , β_{pk} are reduction factors taking into account the effect of long joint, large grip length and packing plate respectively.



for long joints (β_{lj}) • apply when $l_j > 15d$

$$\beta_{lj} = 1.075 - \frac{l_j}{200d}$$

d → dia of bolt

Also $0.75 \leq \beta_{lj} \leq 1$

length of joint





l_j → c/c distance b/w the extreme bolts in the dirⁿ of load transfer

For large grip length (β_{lg}) • apply when $l_g > 5d$

$$\beta_{lg} = \frac{8d}{l_g + 3d}$$


$$\beta_{lg} \geq \beta_{lj} \quad \& \quad l_g \geq 8d$$



for packing plate (β_{pk}) • apply when $t_{pk} > 6\text{mm}$

$$\beta_{pk} = 1 - 0.0125 t_{pk}$$

$t_{pk} \rightarrow$ thickness of thicker packing plate in mm.



② Bearing strength of Bolt :-

$$V_{dpb} = \frac{V_{npb}}{\gamma_{mb}} = \frac{2.5 K_b d t f_u}{\gamma_{mb}}$$

$$K_b = \min \left\{ \frac{e}{3d_o}, \frac{p}{3d_o} - 0.25, \frac{f_{ub}}{f_u}, 1 \right\}$$

$d \rightarrow$ nominal dia of bolt

$t \rightarrow$ sum of thicknesses of plate experiencing bearing in the same dirⁿ


$e \rightarrow$ end distance in the bearing dirⁿ

$p \rightarrow$ pitch distance in the bearing dirⁿ


$d_o \rightarrow$ Dia of bolt hole

$f_{ub} \rightarrow$ ultimate Tensile strength of bolt


$f_u \rightarrow$ ultimate Tensile strength of plate




$$t = \min(t_1, t_2)$$



$$t = \min\{tc_1 + tc_2, tm\}$$





for Bolt ①, $t = \min \{ t_1, t_4 + t_5 \}$

for Bolt ②, $t = \min \{ t_2, t_4 + t_5 \}$

③

Tensile strength of bolt :-

Net section rupture

$$T_{dn} = \frac{0.9 f_{ub}}{\gamma_{mb}} A_{nb}$$

Gross section yielding

$$T_{dg} = \frac{f_{yb}}{\gamma_{mo}} A_{sb}$$

$$A_{nb} \rightarrow \text{net Area} = 0.78 A_{sb}$$

$$\gamma_{mb} \rightarrow 1.25, \gamma_{mo} \rightarrow 1.1$$

The yielding criteria is checked so that excessive yielding doesnot result in non-functional joint before Rupture.


Ques: calculate the strength of M20 bolt Grade 4.6 for following cases

The main plates to be joined are 12 mm thick and Fe410

- i) lap joint
- ii) single cover butt joint with cover plate 10 mm thick
- iii) double cover butt joint with thickness of each cover plate 8 mm.

$$\begin{aligned}
 f_u &= 410 \text{ mpa} & f_y &= 250 \text{ mpa} \\
 f_{ub} &= 400 \text{ mpa} & f_{yb} &= 240 \text{ mpa} \quad \{ 400 \times 0.6 \} \\
 d &= 20 \text{ mm} & d_o &= 20 + 2 = 22 \text{ mm} \\
 \text{Main plate } t &= 12 \text{ mm}
 \end{aligned}$$

(i) lap joint



single shear case

assume 1
1 $l_g < 5d$
1

$$a) V_{dsb} = \frac{f_{ub}}{\sqrt{3} \gamma_{mb}} [n_p A_{nb} + n_s A_{sb}] \beta_t \beta_{lg} \beta_{pk}$$

$$V_{dsb} = \frac{400}{\sqrt{3} \times 1.25} \left[1 \times 0.78 \times \frac{3.14}{4} \times 20^2 + 0 \times \frac{3.14}{4} \times 20^2 \right] 1 \times 1 \times 1$$

$$\underline{V_{dsb} = 45.27 \text{ kNm}}$$

$$b) V_{dpb} = \frac{2.5 K_b d t f_u}{\gamma_{mb}}$$

$$K_b = \begin{cases} \frac{e}{3d_o} & \frac{e}{3d_o} \leq 0.25, \frac{f_{ub}}{f_u}, 1 \\ \frac{P}{3d_o} & \frac{e}{3d_o} > 0.25, \frac{f_{ub}}{f_u}, 1 \end{cases}$$


1.5d_o 2.5d

$$V_{dpb} = \frac{2.5 \times 0.5 \times 20 \times 12 \times 410}{1.25}$$

$$K_b = \begin{cases} 0.5 \\ \text{Min} \end{cases}$$

$$\underline{V_{dpb} = 98.4 \text{ kN}}$$

(ii)



M 20

$d = 20 \text{ mm}$

$d_o = 22 \text{ mm}$

Fe 410, class 4.6

$$V_{db} = \min [V_{dsb}, V_{dpb}]$$


single shear case

$$V_{dsb} = 45.27 \text{ kN}$$

$$V_{dpb} = \frac{2.5 k_b d t f_u}{\gamma_{mb}} = \frac{2.5 \times 0.5 \times 20 \times 10 \times 410}{1.25}$$

$$V_{dpb} = 82 \text{ kN}$$

(c)



M 20

$d = 20 \text{ mm}$

Fe 410, class $\rightarrow$ 4.6

$d_o = 22 \text{ mm}$

$$V_{dsb} = \frac{f_{ub}}{\sqrt{3} \gamma_{mb}} [n_n A_{nb} + n_s A_{sb}]$$

$$= \frac{400}{\sqrt{3} \times 1.25} \left[1 \times \frac{\pi}{4} \times 20^2 \times 0.78 + 1 \times \frac{3.14}{4} \times 20^2 \right]$$

$$= 103.27 \text{ kN}$$

$$V_{dpb} = \frac{2.5 k_b d t f_u}{\gamma_{mb}} = \frac{2.5 \times 0.5 \times 20 \times 12 \times 410}{1.25} = 98.40 \text{ kN}$$

$$\Rightarrow V_{db} = (\text{bolt value}) = \min(103.27, 98.40) = 98.40 \text{ kN}$$

NOTE

Generally in case of single shear, shearing capacity govern and in case of Double shear bearing capacity governs.

Strength of plate:-

The plate may fail by ① shear failure of plate

② Bearing failure of plate

③ Tensile failure of plate
or Net sec^r Rupture


④ Yielding of plate / Gross sec^r Yielding

⑤ Block shear failure ⑥ joint

① shearing and bearing failure of plate may be avoided by selecting proper end and pitch distances.

② Bearing failure can be also controlled by limiting bearing capacity of bolt

③ Tension / Rupture / Tearing of plates



$$T_{dn} = \frac{0.9 f_u}{\gamma_{m1}} \cdot A_n$$

$$A_n = (B - 2d_o)t$$


f_u → ultimate strength of plate

T_{dn} → Design Tensile strength of plate in Rupture

γ_{m1} → partial safety factor @ ultimate stress (1.25)


A_n → Net effective area of member

a)



$$A_n = (B - 2d_o) t$$

b)



$$A_{n(1-1)} = (B - d_o) t$$

$$A_{n(2-2)} = \left[B - 3d_o + \frac{P_1^2}{4g_1} + \frac{P_2^2}{4g_2} \right] t$$

$$A_n = \left[B - nd_o + \sum_{i=1}^m \frac{P_i^2}{4g_i} \right] t$$

$n \rightarrow$ no. of bolts along the failure line

$m \rightarrow$ no. of inclined lines

$B \rightarrow$ width of plate

$t \rightarrow$ thickness of plate

④ yielding of plate

- Yielding of plate is generally not considered at joint location
- Due to excessive yielding of the member in Gross section, the structure may be non-functional.

$$T_{dg} = \frac{f_y}{\gamma_{m0}} \cdot A_g = \frac{f_y}{\gamma_{m0}} B \cdot t$$


→ Design strength in yielding

γ_{m0} → partial safety factor in yielding (1.1)

f_y → Yield strength


⑤ Block shear failure

(i) shear yielding + Tensile Rupture





$$T_{db1} = \frac{f_y}{\sqrt{3} \gamma_{m0}} A_{vg} + \frac{0.9 f_u}{\gamma_{m1}} A_{tn}$$

(ii) Shear Rupture + Tensile yielding



$$T_{db2} = \frac{0.9 f_u}{\sqrt{3} \gamma_{m1}} A_{vn} + \frac{f_y}{\gamma_{m0}} A_{tg}$$

$$T_{db} = \min. \{ T_{db1}, T_{db2} \}$$



- Block shear failure is characterized by tearing out of a segment or block of material at the end of member
- It occurs along a path involving tension on one plane and shear on perpendicular plane
- For block shear failure to occur, one of the plane ruptures while other yields
- yielding always occurs in Gross Area and rupture on Net area.

NOTE Block shear failure generally occurs when material with high bearing strength and high strength bolts are used resulting in smaller length of connection.

Efficiency of joint :- $\eta_{\text{joint}} = \frac{\text{strength of joint}}{\text{Strength of solid plate without reduction of bolt Area}}$

Strength of joint = Min. {

- Shearing of bolt
- Bearing of Bolt
- Tearing of plate
- Block shear failure
- shearing of plate
- Bearing of plate
- failure of cover plate

} $n \times V_{db}$

Strength of solid plate = min. {

- $\frac{0.9 f_u \cdot A_g}{\gamma_{m1}}$
- $\frac{F_y \cdot A_g}{\gamma_{m0}} \checkmark$


The strength of solid plate will be generally Governed by Yielding.


For efficient utilization of material Failure of bolt and plate should be simultaneous.

Arrangement of Bolts :-

By considering diffⁿ arrangement of bolts, tearing strength of plate can be changed and hence efficiency of joint can be changed.

(i) chain Bolting





$$T_{dn (1-1)} = (B - 3d_o) t_m \times \frac{0.9 F_u}{\gamma_{m1}}$$

$$T_{dn (2-2)} = (B - 3d_o) t_m \times \frac{0.9 F_u}{\gamma_{m1}} + 3 V_{db}$$


$$T_{dn (3-3)} = (B - 3d_o) t_m \times \frac{0.9 F_u}{\gamma_{m1}} + 6 V_{db}$$

So tearing strength of 2nd and 3rd section will be higher compare to secⁿ ① and hence most critical secⁿ for Main plate is secⁿ ①


Max. force in cover plate will be at secⁿ ③

Tearing strength of cover plate @ ③ = $(B - 3d_o) (2t_c) \frac{0.9 F_u}{\gamma_{m1}}$
 2 cover plate

(ii) staggered bolting :-



chain bolting $T_{dn (1-1)} = (B - 2d_o) t_m \left(\frac{0.9 F_u}{\gamma_{m1}} \right)$




$$T_{dn (1-1)} = (B - d_o) t_m \left(\frac{0.9 f_u}{\gamma_{m1}} \right)$$

$$T_{dn (2-2)} = \left[B - 2d_o + \frac{P_1^2}{4g_1} \right] t_m \left(\frac{0.9 f_u}{\gamma_{m1}} \right)$$

Staggered bolting is better compared to chain bolting because tearing strength will be higher for staggered bolting.

(iii) Diamond bolting



for main plate

$$T_{dn (1-1)} = (B_1 - d_o) t_m \left(\frac{0.9 f_u}{\gamma_{m1}} \right)$$

$$T_{dn (2-2)} = (B_1 - 2d_o) t_m \left(\frac{0.9 f_u}{\gamma_{m1}} \right) + V_{db}$$

$$T_{dn (3-3)} = (B_1 - 3d_o) t_m \left(\frac{0.9 f_u}{\gamma_{m1}} \right) + 3V_{db}$$

→ If $-d_o t_m \left(\frac{0.9 f_y}{\gamma_{m1}} \right) + V_{db}$ is > 0 then secⁿ 2-2 is stronger compare to secⁿ 1-1

→ The Tearing strength of Main plate will be the Min. of Tearing strength of secⁿ ①, ② and ③

→ If secⁿ 2-2 is not critical then secⁿ 3-3 can't be critical.

→ For cover plate secⁿ 3-3 is most critical because at that secⁿ cover plate is having Max^m force and Max^m reduction of Area due to bolt hole.


→ Diamond pattern is most efficient and economical compare to chain bolting because for a given force, width or thickness requirement of main plate will be less.

NOTE • Thickness of cover plate can be increases without any much loss of economy because cover plate is shorter in length. Normally the combined thickness of the cover plate $>$ that of Main plate

• For double cover butt joint thickness of one cover plate $\leq \frac{5}{8}$ times main plate thickness

• for single cover butt joint, thickness of cover plate shall not be less than $\frac{9}{8}$ × thickness of Main plate

Que. Two plates of Fe410 Grade steel each (210x8) mm are to be joined using 20 mm dia, 4.6 Grade to form a lap joint, the joint is supposed to transfer a factored load of 250 kN. Design the joint and determine suitable pitch for the bolt.



Fe 410, M20, BOLT class = 4.6

$F_u = 410 \text{ MPa}$, $F_{ub} = 400 \text{ MPa}$ $d = 20 \text{ mm}$

$F_y = 250 \text{ MPa}$, $F_{yb} = 240 \text{ MPa}$ $d_o = 22 \text{ mm}$

$P_u = 250 \text{ kN}$

single shear case

$$V_{dsb} = 45.27 \text{ kN}$$

$$V_{dpb} = \frac{2.5 K_b d t f_u}{\gamma_{mb}}$$

$$K_b = \min \left[\frac{e}{3d_o}, \frac{p}{3d_o} - 0.25, \frac{F_{ub}}{F_u}, 1 \right] = 0.50$$

$\xrightarrow{1.5d_o}$ $\xrightarrow{2.5d}$
 $\nearrow$ $\nwarrow$

$$V_{apb} = \frac{2.5 \times 0.5 \times 20 \times 8 \times 410}{1.25} = 65.60 \text{ kN}$$

$$V_{ab} = \min [45.27, 65.60] = 45.27 \text{ kN}$$

$$\Rightarrow \text{NO. OF bolts} = \frac{250}{45.27} = 5.52$$

provide 6 bolts

Consider the distance b/w the bolts as p , and calculate strength of joint per pitch length of the plate. Here, p is in transverse dirⁿ of load.

$$\text{The strength of bolts per pitch length} = 2 \times 45.27 = 90.54 \text{ kN}$$

Let us calculate the p value by equating strength of plate per pitch length = Bolt strength per pitch length.

$$(P - d_o) + \left(\frac{0.9 F_u}{\gamma_{m1}} \right) = 90.54$$


$$(P - 22) \times 8 \times \left(\frac{0.9 \times 410}{1.25} \right) = 90.54 \times 10^3 \text{ N}$$

$$P \geq 60.33 \text{ mm}$$

Min Gauge provided shall be $2.5d = 50 \text{ mm}$

$$\text{adopt } p = \underline{65 \text{ mm}} \text{ and } e = \frac{210 - 2 \times 65}{2} = 40 \text{ mm} > 1.5d_o$$

Block Shear Failure




$$A_{vg} = (40+50) \times 8 \times 2 = 1440 \text{ mm}^2$$

$$A_{tn} = (2 \times 65 - 2 \times 22) \times 8 = 688 \text{ mm}^2$$

$$T_{db1} = \frac{f_y}{\sqrt{3} Y_{m0}} \cdot A_{vg} + \frac{0.9 f_u}{Y_{m1}} A_{tn}$$

$$T_{db1} = \frac{250}{\sqrt{3} \times 1.1} \times 1440 + \frac{0.9 \times 410}{1.25} \times 688 = 392.05 \text{ kN}$$



$$A_{vn} = (40+50-1.5d_o) \times t \times 2$$

$$A_{vn} = 912 \text{ mm}^2$$

$$A_{tg} = (65+65) \times 8 = 1040 \text{ mm}^2$$

$$T_{db2} = \frac{0.9 f_u}{\sqrt{3} Y_{m1}} A_{vn} + \frac{f_y}{Y_{m0}} A_{tg}$$

$$= \frac{0.9 \times 410 \times 912}{\sqrt{3} \times 1.25} + \frac{250 \times 1040}{1.1} = 391.79 > 250 \text{ kN}$$

Que. calculate efficiency of joint of the previous question.

$$\text{Strength of joint} = \min \begin{cases} n \times V_{db} \\ \text{Tearing strength of plate} \\ \text{Block shear failure} \end{cases}$$

$$n \times V_{db} = 6 \times 45.27 = 271.62 \text{ kN}$$

$$\text{Tearing strength of plate} = 340.07 \text{ kN}$$

$$\left\{ (B - 3d_o) t \frac{0.9 f_u}{\gamma_{m1}} \right.$$

$$\text{Block shear failure} = \min(T_{db1}, T_{db2}) = 391.79 \text{ kN}$$


$$\text{Strength of joint} = 271.62 \text{ kN}$$

$$\text{Strength of solid plate} = \frac{f_y}{\gamma_{m0}} \cdot A_g = \frac{250 \times 210 \times 8}{1.1} = 381.81 \text{ kN}$$

$$\text{Gross Rupture} = \frac{0.9 f_u}{\gamma_{m1}} = \frac{0.9 \times 410}{1.25} = 495 \text{ kN}$$

$$\eta_{\text{joint}} = \frac{271.62 \text{ kN}}{381.81} \times 100 = 71.14\%$$

Que.



Find p for most economical utilization of material.
 $f_u = 410 \text{ MPa}$, $t = 10 \text{ mm}$, bolt M20 & 4.6 class.

For most economical utilization of material, the strength of repeating pattern of width $2P$ in tearing shall be equal to strength of bolt in shearing or bearing.

$$V_{dsb} = 45.27 \text{ kN (for M20, 4.6)}$$

$$V_{dpb} = \frac{2.5 k_b d t f_u}{\gamma_{mb}}$$

$$k_b = \min \left\{ \frac{e}{3d_o}, \frac{p}{3d_o}, \frac{f_{ub}}{f_u}, 1 \right\} = 0.50$$

$\xrightarrow{1.5d_o} \xrightarrow{2.5d}$
 $\xrightarrow{400}$
 $\xrightarrow{410}$

$$V_{dpb} = \frac{2.5 \times 0.5 \times 20 \times 10 \times 410}{1.25} = 82 \text{ kN}$$

$$V_{db} = \min \{ 45.27, 82 \}$$

$$= 45.27 \text{ kN}$$

Strength of all the bolts in one repeating unit

$$= 3 \times 45.27 = 135.81 \text{ kN}$$


Strength of plate in Rupture (2p width)

$$T_{dn(1-1)} = (2p - 2d_o) t \frac{0.9 f_u}{\gamma_{m1}}$$

For most economical utilization

$$(2p - 2d_o) t \frac{0.9 f_u}{\gamma_{m1}} = 135.81 \times 10^3$$

$$p = 45.00 \text{ mm}$$




In this case the pitch/Gauge shall be min. of $2.5d$ considering the Gauge distance b/w two parallel lines of bolt. Min. Gauge = $2.5d = 50 \text{ mm}$ so in this case the distance $2p$ shown in figure shall be 100 mm .

If we consider failure along 1-1 then Φ

$$T_{dn(1-1)} = (B - 3d_o + \frac{2n^2}{4g}) \times \frac{0.9 f_u}{\gamma_{m1}}$$

$$= \left(50 - 3 \times 22 + \frac{2 \times 50^2}{4 \times 50} \right) \times 10 \times \frac{0.9 \times 410}{1.25} = 174.16 \text{ kN}$$

Que Find the Max. Force that can be transferred through double cover butt joint as shown in the figure below. Also find the efficiency of joint. Bolts $\rightarrow$ M20, 4.6 plate Fe410



thickness of Main plate = 16 mm each corner plate = 10 mm

in double cover butt joints bolts are in double shear
 shearing strength of bolt = $\frac{45.27}{0.78} \times 1.78 = 103.31 \text{ kN}$

$$V_{dsb} = \frac{f_{ub}}{\sqrt{3} \gamma_{mb}} [n_n A_{nb} + n_s A_{sb}] \beta_{Lj} \beta_{Lg} \beta_{Pk}$$

joint length = c/c distance b/w end distance bolts.
 $= 2 \times 60 = 120 < 15d$

$$\beta_{Lj} = 1$$

l_g i.e grip length = $2 \times 10 + 16 = 36 \text{ mm} < 5d$

$$\beta_{Lg} = 1$$

NO packing plate = $\beta_{Pk} = 1$

$$V_{dsb} = \frac{400}{\sqrt{3} \times 1.25} \left[1 \times 0.78 \times \frac{3.14}{4} \times 20^2 + 1 \times \frac{\pi}{4} \times 20^2 \right] \times 1 \times 1 \times 1$$

$$V_{dsb} = 103.30 \text{ kN}$$

$$V_{dpb} = \frac{2.5 K_b d t f_t}{\gamma_{mb}}$$

$$K_b = \min \left\{ \frac{e}{3d_o}, \frac{P}{3d_o}, \frac{f_{ub}}{f_u}, 1 \right\} = 0.606$$

$\begin{matrix} \nearrow 40 \\ \searrow 22 \end{matrix} \quad \begin{matrix} \nearrow 60 \\ \searrow 22 \end{matrix} \quad \begin{matrix} \nearrow 400 \\ \searrow 410 \end{matrix}$

$$V_{dpb} = \frac{2.5 \times 0.606 \times 20 \times \min(2 \times 10, 16) \times 410}{1.25}$$

$$V_{dpb} = 159.01 \text{ kN}$$

$$V_{db} = \min \{ 103.3, 159.01 \} = 103.3 \text{ kN}$$

so force capacity = $6 \times 103.3 = 619.8 \text{ kN} \quad \text{---(i)}$

$$T_{dn(1-1)} = \frac{(B - d_o)t \cdot 0.9 \times f_u}{\gamma_{m1}}$$

$$= \frac{(360 - 22) \times 16 \times 0.9 \times 410}{1.25} = 1596.44 \text{ kN}$$

$$T_{dn(2-2)} = \frac{(B_m - 2d_o)t \cdot 0.9 \times f_u}{\gamma_{m1}} + V_{db}$$

$$= \frac{(360 - 2 \times 22) \times 16 \times 0.9 \times 410}{1.25} + 3 \times 103.3 \times 10^3$$

$$= \boxed{1595.84 \text{ kN}} \quad \checkmark * \quad \text{--- (ii)}$$

$$T_{dn(3-3)} = \frac{(B_m - 3d_o)t \cdot 0.9 \times f_u}{\gamma_{m1}} + 3V_{db}$$

$$= \frac{(360 - 22 \times 3) \times 16 \times 0.9 \times 410}{1.25} + 3 \times 103.3 \times 10^3$$


$$= 1698.52 \text{ kN}$$

We can also consider possible staggered failure plane
Tearing strength of cover plate

$$T_{tn(3-3)} = \frac{(B_c - 3d_o)t_c \cdot 0.9 f_u}{\gamma_{m1}}$$

$$= \frac{(200 - 3 \times 22) \times 2 \times 10 \times 0.9 \times 410}{1.25} = 791.2 \text{ kN}$$

$$\quad \checkmark \text{ (iii)}$$



$$A_{vn} = (40 + 2 \times 60 + \frac{d_o}{2} - d_o) \times t_m \times 2 = 4768 \text{ mm}^2$$

$$A_{tg} = 4 \times 30 \times 16 = 1920 \text{ mm}^2$$

$$T_{db1} = \frac{0.9 f_u}{\gamma_3 \gamma_{m1}} A_{vn} + \frac{f_y}{\gamma_{m0}} \times A_{tg} = 4373.$$

$\xrightarrow{410}$ $\xrightarrow{250}$
 $\downarrow 1.25$ $\downarrow 1.1$

$$T_{db1} = 1248.9 \text{ kN}$$


Generally no need to check block shear failure.

$$\text{Strength of joint} = \text{Min. } \{ 619.8, 1595.84, 791.2 \}$$


$$= 619.8 \text{ kN}$$

$$\text{efficiency of joint} = \frac{619.8}{\frac{f_y}{\gamma_{m0}} \cdot B_{mtm}} = \frac{619.8}{\frac{250}{1.1} \times 360 \times 16} \times 100 = 47.34\%$$

Bolt Subjected to combined shear & Tension



$$\left(\frac{V_{sb}}{V_{db}} \right)^2 + \left(\frac{T_b}{T_{db}} \right)^2 \leq 1$$



In most cases when bolts are subjected to both shear and Tension, the connection is loaded eccentrically. However in some cases the member force can pass through the centroid of connection as shown above



$V_{sb} \rightarrow$ factored shear force in bolt

$V_{db} \rightarrow$ shear capacity or Bearing capacity Design (Bolt Value)

$T_b \rightarrow$ Factored Tensile force in bolt

$T_{db} \rightarrow$ Design Tension capacity of bolt.

prying forces




$Q \rightarrow$ prying force

Due to flexibility of connection i.e. connected part when the bolts are subjected to direct tensile load, bolts develop additional forces called prying forces.

- prying action increases the Tensile force in bolt
- it can be reduced by using thick plate or by limiting the lever arm, i.e. the distance b/w bolts

* In case of ∞ rigid plate, prying force = 0

Que check the safety of the joint shown below
8 no. of M16 bolts of 4.6 fixed for making
the connection @ secⁿ ①-①. Neglect the effect of
prying action. Also find the no. of 16mm dia bolts
of Grade 4.6 to connect the double Angle secⁿ (8mm
thick angle) with the Web of the T-bracket



the bolt @ locⁿ ① are in direct shear and direct tension
vertical force due to P_4 $P_V = 200 \sin 45 = \frac{200}{\sqrt{2}} \text{ kN}$

$$P_H = 200 \cos 45 = \frac{200}{\sqrt{2}} \text{ kN}$$

$$\text{Direct shear per bolt} = \frac{200}{\sqrt{2} \times 8} = 17.68 \text{ kN}$$

$$\text{Direct Tension per bolt} = 17.68 \text{ kN}$$

$$V_{dpb} = \frac{2.5 k_b d t f_u}{\gamma_{mb}}$$

$$k_b = \min \left\{ \overset{1.5d}{\frac{e}{3d_o}}, \overset{2.5d}{\frac{P}{3d_o} = 0.25}, \overset{400}{\frac{f_{ub}}{f_u}, 1} \right\} = 0.49$$

18 410

~~$$V_{dsb} = \frac{P_{ub}}{\sqrt{3} \gamma_{mb}} \times 0.78 A_{sb}$$~~

$$V_{dsb} = \frac{P_{ub}}{\sqrt{3} \gamma_{mb}} \times 0.78 A_{sb} = 28.97 \text{ kN}$$

$\frac{\pi}{4} (16)^2$

$$V_{dpb} = \frac{2.5 \times 0.49 \times 16 \times 10 \times 410}{1.25} = 64.28 \text{ kN}$$

$$V_{db} = \min \{ 28.97, 64.28 \} = 28.97 \text{ kN}$$

$$T_{db} = \min \left\{ \frac{0.9 f_{ub}}{\gamma_{mb}} \times A_{nb}, \frac{f_y}{\gamma_{mo}} \times A_{sb} \right\}$$

$$= \min \left\{ \frac{0.9 \times 400}{1.25} \times 0.78 \times \frac{\pi}{4} \times 16^2, \frac{240}{1.1} \times \frac{\pi}{4} (16)^2 \right\}$$

$$= \min \{ 45.15, 43.85 \}$$

$$= 43.85 \text{ kN}$$

$$\left(\frac{V_{sb}}{V_{db}} \right)^2 + \left(\frac{T_b}{T_{db}} \right)^2 = \left(\frac{17.67}{28.97} \right)^2 + \left(\frac{17.67}{43.85} \right)^2$$

$$= 0.535 < 1 \quad \underline{\text{safe}}$$

The double angle secⁿ connected back to back on opposite side of the T-bracket. in this case the bolt will be in double shear $\Rightarrow$

$$V_{dsb} = \frac{28.97}{0.78} \times 1.78 = 66.11 \text{ KN}$$


$$V_{dptb} = \frac{2.5 k_b d t f_u}{\gamma_{mb}}$$

$$= \frac{2.5 \times 0.49 \times 16 \times 10 \times 410}{1.25} = 64.28 \text{ KN}$$

$$V_{db} = \min(66.11, 64.28) = 64.28 \text{ KN}$$

$$\text{No. of bolts required} = \frac{200}{64.28} = 3.11, \text{ provide } \rightarrow 4$$


NOTE In case of connection of two plates of Diffⁿ thicknesses using double cover butt joint we need to calculate the strength of joint as well as plate for both side and the smaller Value shall be taken as the strength of the joint



$$\textcircled{2} V_{db} = \min \left\{ \frac{f_{ub}}{\sqrt{3} \gamma_{mb}} (n_n \cdot A_{nb} + n_s \cdot A_{sb}) \times B_{pk}, \frac{2.5 k_b d t f_u}{\gamma_{mb}} \right\}$$

$$\textcircled{1} V_{db} = \min \left\{ \frac{f_{ub}}{\sqrt{3} \gamma_{mb}} (n_n \cdot A_{nb} + n_s \cdot A_{sb}), \frac{2.5 k_b d t f_u}{\gamma_{mb}} \right\}$$

$\downarrow \min\{t_{cover}, t_1\}$



$F_1 = F_2 \rightarrow$ No Bolt


o/w $|F_1 - F_2|$ is the Bolt


- For a continuous member, connection in the gusset plate shall be designed for a force of $|F_1 - F_2|$
- For discontinuous member, connection shall be designed for the respective forces.

Eccentrically loaded connections :- Depending on how the bolts are placed in a connection, bolts can be subjected to ① direct load and twisting moment (Type-1 connection)

② Direct load & BM (Type-2 connection)


① Direct load + Twisting moment (Type-1)





$$F_{Di} = \frac{P}{\sum_{i=1}^n A_i} \cdot A_i = \frac{P}{n A_i} \cdot A_i = \frac{P}{n} \quad (\text{for same dia bolt})$$

$F_{Di} \rightarrow$ Direct force in i^{th} bolt



The line of action of F_{Di} is taken parallel to the line of applied force.

$$\tau = \frac{T \cdot r}{J}$$

$$F_{Ti} = \frac{T \cdot r_i \cdot A_i}{J}$$

$$F_{Ti} = \frac{T \cdot r_i}{\sum_{i=1}^N A_i r_i^2} \cdot A_i = \frac{T \cdot r_i}{\sum r_i^2}$$

for same dia bolts.

F_{Ti} = Torsional shear force in i^{th} bolt
for same Dia bolt Torsional SF $\propto Y_i$
ie Distance from centroid of bolt group.

Dirⁿ of F_{Ti} is $\perp$ to line joining the C.G. of bolt group and i^{th} bolt and will be in the same sense as that of torsional moment.


The resultant SF in i^{th} bolt

$$F_{ri} = \sqrt{F_{Di}^2 + F_{Ti}^2 + 2 F_{Di} F_{Ti} \cos \theta}$$

For safety of the bolt $F_{ri} < V_{db}$ (i.e. Bolt Value)

NOTE $\Rightarrow$ The above analysis is elastic analysis

- In case bolts are of equal dia and arrangement is symmetrical the farthest bolt will carry Max. Resultant force or Various farthest bolt the one which angle b/w F_{Di} and F_{Ti} is least is the most critical so in this case bolt ① & ③ can be most critical
- In general the bolt which is closest to the line of action of the force is the most critical.
- In plastic or strength analysis, it is assumed that eccentrically loaded bolt group rotates about an instantaneous center of rotation
Elastic analysis is more conservative.
- To Design the eccentric connection We've to assume no. and arrangement of bolts.



$$n = \sqrt{\frac{6M}{m p V_{db}}}$$

$M \rightarrow$ Twisting moment
 $= p \cdot e$


$p \rightarrow$ pitch

$V_{db} \rightarrow$ bolt value

$n \rightarrow$ no. of bolts per line

$m \rightarrow$ no. of lines of bolts.

② Direct load and BM



Bolts above NA $\rightarrow$ subjected to shearing and bearing, & Tension


Bolts below NA $\rightarrow$ Bearing & shearing, No comp. stress

Above the top bolt, bracket will lose contact and hence h will be up to center line of top bolt.

- compressive stresses are resisted by flange of I-secⁿ below the NA
- safety of the bolts that are in shearing, bearing and tension can be checked using interaction eqⁿ i.e

$$\left(\frac{V_{sb}}{V_{db}} \right)^2 + \left(\frac{T_b}{T_{db}} \right)^2 \leq 1.0$$

Que.



$$d_{19} = \begin{cases} 1 \rightarrow 6 \Rightarrow d \\ 7 \Rightarrow 1.2d \end{cases}$$

Find the force in 7th bolt.

$$F_{R7} = \sqrt{F_{D7}^2 + F_{T7}^2 + 2 F_{D7} F_{T7} \cos \theta}$$

$$F_{D7} = \frac{P_u \cdot A_7}{\sum_{i=1}^7 A_i} = \frac{P_u (1.2d)^2}{6d^2 + (1.2d)^2} = \frac{P_u \times 1.44}{7.44} = 19.35 \text{ kN}$$

$$F_{T7} = \frac{T \cdot Y_7}{J} \cdot A_7$$

C.G of bolt Group

$$\bar{X} = \frac{3A \times 0 + 3A \times 80 + 1.44A \times 160}{7.44A} = 63.22 \text{ mm.}$$

$$\bar{Y} = \frac{3.44A \times 0 + 2A \times 80 + 2A \times 160}{7.44A} = 64.52 \text{ mm.}$$

$$T = P_u \cos \beta (80 - \bar{X}) + P_u \sin \beta (160 - \bar{X})$$

$$T = 100 \cos 26.56 (80 - 63.22) + 100 \times \sin 26.56 (160 - 64.52)$$

$$T = 5.77 \text{ kNm.}$$

$$F_{T7} = \frac{T \cdot Y_7}{J} A_7$$

$$J = \sum_{i=1}^7 A_i Y_i^2$$

$$Y_1 = \sqrt{(\bar{X})^2 + (160 - \bar{Y})^2} = 114.59 \text{ mm}$$

$$Y_2 = \sqrt{\bar{X}^2 + (80 - \bar{Y})^2} = 65.08 \text{ mm}$$

$$Y_3 = \sqrt{\bar{X}^2 + \bar{Y}^2} = 90.33 \text{ mm}$$

$$Y_4 = \sqrt{(80 - \bar{X})^2 + (160 - \bar{Y})^2} = 96.94 \text{ mm}$$

$$Y_5 = \sqrt{(80 - \bar{X})^2 + (80 - \bar{Y})^2} = 22.83 \text{ mm}$$

$$Y_6 = \sqrt{(80 - \bar{X})^2 + \bar{Y}^2} = 66.67 \text{ mm}$$

$$Y_7 = \sqrt{(160 - \bar{X})^2 + \bar{Y}^2} = 116.31 \text{ mm}$$

$$F_{T7} = \frac{T \cdot \gamma_7 \cdot A_7}{A (114.51^2 + 65.08^2 + 90.33^2 + 96.94^2 + 22.83^2 + 66.67^2 + 116.31^2 \times 1.44)}$$

$\nearrow 5.77 \times 10^3$
 $\nearrow 116.31$
 $\nearrow 1.44 A$

$$F_{T7} = 16.28 \text{ KN}$$

$$\theta = 60.25^\circ$$

$$F_{R7} = \sqrt{F_{D7}^2 + F_{T7}^2 + 2 F_{D7} F_{T7} \cos \theta}$$

$$F_{R7} = 30.85 \text{ KN}$$

④ WELDED CONNECTIONS

- Generally in structural work we use electrical arc welding.
- Due to sparking, temp. rises to about $3300^{\circ} - 5000^{\circ}\text{C}$.
The welding rod is coated that deposits slag and prevents contact of atmospheric agent with the molten weld metal.
This prevents the changes of corrosion and weld defects.

+ve

- * In case of welding complicated shapes can be welded and alteration can be easily done.

Also DL of structure will be also less* than that of bolted structure. No cover plate required and less expensive.

The rigidity of welded connection will be higher than that of bolted connection (bearing bolt)

-ve

- * Requires highly skilled labour, inspection is difficult and expensive and Fillet weld is prone to fatigue failure.

However in general welding is better than bolting.


Various types of weld.

- ① Butt Weld
- ② Fillet Weld
- ③ Plug Weld
- ④ Slot Weld


① Butt Weld used to connect structural member that are aligned in same plan.

Diffⁿ types of Butt weld are:-


Square butt weld



Single V



Double V



single bevel


Double bevel

Single U

Double U

single J

Double J



- square butt weld is provided for secⁿ less than 8 mm thick

- single U, V, J for 12-40 mm thick plate
Double U, V, J for plate thickness > 40 mm


- Butt weld is more suitable ^{*} for alternating stresses providing complete penetration is ensured

- Due to stress concⁿ R/F is not suitable for alternating stress and in this case Weld surface is made Flush.
However R/F makes butt weld stronger in static load.

Weld code $\rightarrow$ IS 816
for Metal Arc Welding.


In any case the R/F shouldn't exceed 3mm
if the weld metal is deposited in complete thickness,
butt weld is called complete penetration butt weld o/w
partial penetration butt weld.

In case of complete penetration butt weld, strength of
connection is taken equal to that of the strength of
the parent plate (thinner plate for Diffⁿ thicknesses) *



$$t = \min(t_1, t_2)$$


For incomplete penetration, effective throat thickness is
taken min. thickness of weld common to the parts
being joined.



$$t = \min\{t_1, t_2\}$$


In case ~~of~~ ^{the} full penetration of butt weld is not achieved,
an eff. throat thickness $\left(\frac{7}{8}\right)$ of the thickness of thinner
member shall be provided. However for calculating the
strength, eff. throat thickness is assumed to be $\left(\frac{5}{8}\right)$ *
of thickness of thinner member.

Joining plates with Different thickness and width in
in case of butt weld



if $t_2 - t_1 > \frac{t_1}{4}$ or 3mm, whichever is
greater, we provide tapering in the thicker part to match
the thinner part and tapering should not be greater than


* 1 in 5



if $B_2 - B_1 > \frac{B_1}{4}$ then provide tapering. (1 in 5)


- The above is generally done for structure to take care of Dynamic / repeating or alternating stresses.

Fillet Weld provided when two members to be jointed are in diffⁿ plane





End Fillet Weld is generally stronger than side Fillet Weld. However For design purpose there is no diffⁿ b/w end and side fillet weld. *


Fillet Weld is assumed to resist the load by shearing action on its throat.



Plug Weld



→ Stress diagram without plug weld




Stress dia with plug weld
(more uniform)

*
plug weld is provided to make the stress uniform fill up holes in connection and prevent buckling of overlapping parts.

As per IS code, plug weld is not considered in strength calculations.

Slot Weld




- In case of slot welding, and welding is done along the periferi of slot, it is considered in strength calculation
- Slot weld is provided when the largest size of weld provided in the limited overlap length is not sufficient to resist the load.

Weld symbol



→ Fillet weld






→ square butt weld

V → single V


Y → single U

X → Double U

IMP. for objective



length not need to be mentioned, because it is all rounded welding.




Design of butt Weld

As per IS code butt Weld shall be treated as parent metal with a thickness equal to throat thickness and the stress shall not exceed that permitted in the parent metal.


- A) The design strength of butt Weld in Tension and comp. is governed by yielding *

$$T_{dw} = \frac{f_y}{\gamma_{mw}} l_e t_e$$



PLAN

$f_y \rightarrow$ Min. of yield strength of Weld (f_{yw})
and yield strength of plate (f_y)



$l_e \rightarrow$ eff. length of weld

$t_e \rightarrow$ eff. throat thickness.

$\gamma_{mw} \rightarrow$ partial safety factor, 1.25 for shop Weld
1.5 for field Weld

- B) The design strength of butt Weld in shear is also governed by yielding * and.

$$V_{dw} = \frac{f_y}{\sqrt{3} \gamma_{mw}} l_e t_e$$

Que. two plates of 16 & 14 mm are to be joined by a groove Weld the joint is subjected to a factored tensile force of 430 kN, considering eff. length of Weld = 175 mm check safety of joint

A) for a single V groove Weld

B) for a Double V groove Weld.

Take Fe410

NOTE In case of single V groove weld, incomplete penetration is considered and t_e shall be taken as $\frac{5}{8} \times \min(t_1, t_2)$

$$i) \quad T_{dw} = \frac{f_y}{\gamma_{mw}} t_e t_e$$

$$t_e = \frac{5}{8} \times \min(t_1, t_2) = \frac{5}{8} (14) = 8.75 \text{ mm}$$

$$T_{dw} = \frac{250}{1.5} \times 175 \times 8.75 = 255.20 \text{ kN} < 430 \text{ kN}$$


NOT safe

$$ii) \quad T_{dw} = \frac{f_y}{\gamma_{mw}} t_e t_e$$


$$= \frac{250}{1.5} \times 175 \times \min(14, 16) = 408.33 \text{ kN} < 430 \text{ kN}$$

NOT safe


Design of Fillet Weld



convex fillet weld




(Concave Fillet Weld)



- We can provide concave & convex Fillet Weld.
- Convex Weld is stronger than concave Weld due to higher throat thickness and penetration.
- Concave Weld are most suitable Under alternating stresses because it offers smooth path for the flow of stress.
- In concave fillet Weld there is a chance of crack on cooling hence it is generally made in two passes.
- ✓ The first slightly convex and other is build up to form a concave fillet Weld *


IS code specifications

① size of Weld The largest Right angle triangle that can be inscribed in Weld gives size of Weld. for normal fillet Weld size is taken as min. Weld leg size.




$S_1, S_2 \rightarrow$ size of Weld / leg of Weld
 $\text{size} = \min(S_1, S_2)$

For deep penetration Weld where depth of penetration beyond the root run is min. 2.4 mm, size of Weld is taken as $2.4 \text{ mm} + \text{min. leg size}$



$\text{Weld size} = 2.4 + \min(S_1, S_2)$

(A) Max. size of Fillet Weld



for square edge *


$$\text{Max size} = t - 1.5 \text{ mm}$$

(to avoid chances of Washout)

For round edge.

$$\text{Max size} = \frac{3}{4} t$$

$t \rightarrow$ nominal thickness of round edge



(B) Min. size of Fillet Weld


if we provide very small size of weld, the thicker plate will not be heated properly, and there can be inadequate joint b/w weld metal ~~plate~~ and plate. Also cooling rate of weld metal will be higher compared to that of plate. This can lead to brittle failure of weld or distortion in the joint.

thickness of thicker
plate being joined (mm)

Min. size of weld (mm)

* $t \leq 10 \text{ mm}$	3
$10 < t \leq 20 \text{ mm}$	5
$20 < t \leq 32 \text{ mm}$	6
$32 < t \leq 50 \text{ mm}$	8 for first run and 10 mm minimum (total)


- * When thicker part is more than 50 mm, special precautions like preheating shall be done
- The Min. size however should not be more than thickness of thinner plate being joined.
- The Weld size is generally considered as per the Min. Weld size because.



$$\text{Area} = \frac{5}{\sqrt{2}} \times 100$$

$$\text{Volume} = \frac{1}{2} \times 5 \times 5 \times 100$$

$$= 1250 \checkmark$$



$$\text{Area} = \frac{10}{\sqrt{2}} \times 50$$


$$\text{Volume} = \frac{1}{2} \times 10 \times 10 \times 50$$

$$= 2500$$

- larger size Weld requires more than one run of weld hence the cost increases because of chipping and cleaning, which is required for proper bond of successive runs.
- smaller size weld is cheaper than a larger one for same strength since less Vol^m of welding is req.

✓ However connection length will increase with small weld size so in EXAM consider b/w min. and max. weld size

② Effective throat thickness (t_e)



$$t_e = k_s$$

$s \rightarrow$ size of weld

θ	60-90°	91-100°	101-106°	107-113°	114-120°
K	0.70	0.65	0.60	0.55	0.50

$\theta \rightarrow$ Angle b/w fusion faces


Throat thickness is the Min. thickness on which

Shearing will occur

✓ if $\theta < 60^\circ$, $\theta > 120^\circ$, Fillet Weld not recommended!

The eff. throat thickness for a fillet weld shall not be less than 3mm

③ Effective length



• eff. length is the length of Fillet Weld which is of specified size and req. throat thickness

• eff. length of Fillet Weld = Overall length - 2S

• eff. length $\leq 4S$

• eff. length of butt weld shall be taken as the length of the continuous full size weld but $\leq 4S$

• In the structural drawing the length mentioned is always eff. length.


* Min length req. for a fillet weld to be 100% effective is $4S$. if Min length $\leq 4S$ then eff. size is taken as $\frac{1}{4} \times$ eff. length

• End returns are provided to ~~relieve~~ relieve the weld from high stress concn near the ends. It must be provided for tension

and parts carrying bending loads for welded joints subjected to eccentricity, stress reversal or impact load. End returns shall be taken as $\geq 2 \times \text{size of weld}$. *

- When end of an element is connected only by fillet weld parallel to the dirⁿ of stress then $b \geq l$

$$\underline{\underline{b \geq 16t}}$$



$t \rightarrow$ thickness of thinner plate being joined

$b \rightarrow$ width of smaller plate

if the length of side filled weld exceeds $150 t_e$, strength of weld is reduced by a factor β


$$* \quad \beta = 1.2 - \frac{0.2 l_j}{150 t_e} \leq 1$$

$l_j \rightarrow$ length of welded joint in dirⁿ of load transfer

④ Effective Area

$$A_e = l_e t_e$$

⑤ overlap length



* overlap shant be $< \max. (4t, 400 \text{ mm})$ $\rightarrow$ This will ensure that induced eccentricity is ignored and BM will not be considered.

⑥ Design strength of Fillet Weld

$$P_{dw} = \frac{F_u}{\sqrt{3} \gamma_{mw}} l_e t_e$$


$$t_e = k \cdot s$$

$F_u \rightarrow$ smaller of the ultimate stress of Weld or parent metal


Intermittent Fillet Weld

it may be provided if the length of smallest size weld required is $<$ continuous length of joint

clear spacing b/w eff. length in case of intermittent fillet weld shant be $>$ min. $(12t, 200 \text{ mm})$, for member in Compressing and $>$ $(16t, 300 \text{ mm})$ for member in Tension
 $t \rightarrow$ thickness of thinner part being joined.



chain intermittent Fillet Weld.




Staggered intermittent fillet Weld.

* staggered intermittent fillet weld are structurally better than chain intermittent fillet weld as it reduces distortion due to the balancing nature of weld.
chances of buckling will be less.

Design of plug and slot weld

if the overlap of plate is restricted and the applied force P can't be resisted ~~by~~ given by providing continuous length of weld with max. size of weld we adopt slot welding. *



$$r \leq \max(1.5t, 12 \text{ mm})$$


$$D \text{ or } W \leq \max(3t, 25 \text{ mm})$$

$$t \leq \max(2t, 25 \text{ mm})$$

corners @ enclosed end or slot should be rounded with a radius $\leq \max(1.5t, 12 \text{ mm})$ *

* plug weld shall be considered for strength calculations.

Fillet Weld for Truss Member (Unsymmetrical Member)



$$F_1 = \frac{F_u}{\sqrt{3} \gamma_{mw}} l_1 t_e, \quad F_2 = \frac{F_u}{\sqrt{3} \gamma_{mw}} l_2 t_e, \quad F_3 = \frac{F_u}{\sqrt{3} \gamma_{mw}} l_3 t_e$$

$$T = F_1 + F_2 + F_3$$

$$F_1 x - F_2 (l_3 - x) - F_3 \left(\frac{l_3}{2} - x \right) = 0$$

While designing the connection Weld should be provided @ joint in such a way that resultant of forces resisted through Weld passes through center of gravity of Member.

Que A Tie member consisting of ISA 80x50x8 mm (Fe410) is welded to 12 mm thick gusset plate @ site using Site Fillet Weld only. Design a moment free welded connection to transmit load = Design strength of Member if the longer leg is connected to gusset plate.

$$C_{zz} = 27.3 \text{ mm}, \quad C_{yy} = 12.4 \text{ mm}$$

ISA 80x50x8 mm.

Gusset thickness = 12 mm. Fe410

$$C_{zz} = 27.3 \text{ mm}, \quad C_{yy} = 12.4 \text{ mm}$$

The design force that can be applied in member is -


$$T_{dg} = \frac{F_u}{\gamma_{mo}} \times A_g = \frac{250}{1.1} \times A_g$$


$$A = A_1 + A_2$$

$$A = 976 \text{ mm}^2$$

$$T_{dg} = \frac{250}{1.1} \times 976$$

$$T_{dg} = 221.818 \text{ kN}$$





Min weld size = 5 mm
 Max. weld size = $8 - 1.5 = 6.5$ mm

$F_1 + F_2 = 221.82$ kN

$F_1 \cdot c_{22} = F_2 (80 - c_{22})$

$F_1 \cdot 27.3 = F_2 \cdot 52.7$

$F_1 = \frac{F_2 \times 52.7}{27.3} \Rightarrow F_1 = 1.93 F_2$

$F_1 = 146.12$ kN, $F_2 = 75.696$ kN

$F_1 = \frac{F_u}{\sqrt{3} \gamma_{mw}} \cdot l_1 \cdot t_e$

consider weld size = 6 mm

$t_e = K_s \rightarrow 0.7 \times 6 = 4.2$



$146.12 \times 10^3 = \frac{410}{\sqrt{3} \times 1.5} \times l_1 \times 4.2$

$l_1 = 220.46$ mm

$F_2 = \frac{F_u}{\sqrt{3} \gamma_{mw}} \times l_2 \cdot t_e$

$l_2 = 114.21$ mm

Que. An ISLC 300 (Fe410) is to carry factored tensile load of 900 kN the channel secⁿ is to be welded @ site to a gusset plate of 12 mm thick. Design a fillet weld if overlap is limited to 350 mm. properties of ISLC 300 -



consider weld size of 5 mm.

$$t_e = k_s = 0.7 \times 5 = 3.5 \text{ mm}$$

$$P_h = \frac{f_u}{\sqrt{3}} l_e t_e$$


$$900 \times 10^3 = \frac{410}{\sqrt{3} \times 1.5} l_e \times 3.5$$

$$l_e = 1629.45 \text{ mm}$$

As we've available weld length = $350 + 350 + 300 = 1000 \text{ mm}$
 So we need to provide extra 629.45 mm .
 So we can provide slot welding

let us provide 2 no. of slots with length $\frac{629.45}{4}$
 $= 157.36 \text{ mm} \approx 160 \text{ mm}$

Que. A circular shaft of Dia 150 mm is welded to a Rigid plate by means of 6 mm Around Fillet Weld. Calculate the ultimate twisting moment that can be resisted by the Weld (Fe 410), Shop Welding.



size = 6 mm
 $\gamma_{mw} = 1.25$
 Fe 410


$$\tau = \frac{T \cdot r}{J}$$

$$T = \frac{\tau J}{r}$$

$$\tau = \frac{f_u}{\sqrt{3} \gamma_{mw}} = \frac{410}{\sqrt{3} \times 1.25}$$

$$\tau = 189.37 \text{ MPa}$$

$$T = \frac{189.37 J}{r}$$




$$I_{yy} = (b \cdot te) (\bar{x})^2 + \left[\frac{te \cdot l^3}{12} \left(\frac{l}{2} - \bar{x} \right)^2 \times te \right] \times 2$$

$$F_r = \sqrt{F_D^2 + F_T^2 + 2F_DF_T \cos \theta}$$

For safety of connection $F_r \leq$ permissible stress in Weld

$$F_r \leq \frac{F_u}{\sqrt{3} \gamma_{mw}}$$

Que. Find the size of weld req. on Horizontal & Vertical leg to resist a factored load of 150 kN as shown - Fe410, Shop Welding



consider throat thickness = t_e

$$\bar{X} = \frac{200 \times t_e \times \frac{200}{2} + 300 \times t_e \times 0}{200 \times t_e \times 2 + 300 \times t_e} = 57.14 \text{ mm}$$

$$f_D = \frac{P_u \rightarrow 150 \times 10^3 \text{ N}}{2 \times 200 \times t_e + 300 \times t_e}$$

$$f_D = \frac{214.28}{t_e} \text{ MPa}$$

~~Q11~~ Torsional shear stress. $\tau = \frac{T \cdot r}{J}$

$$T = P_u \times (200 + 100 - \bar{x}) \times 10^{-3}$$

$$T = 150 \times (300 - 57.14) \times 10^{-3}$$

$$T = 36.429 \text{ kN.m}$$

$$r = \sqrt{\left(\frac{300}{2}\right)^2 + (200 - 57.14)^2}$$

$$r = 207.14 \text{ mm}$$

$$J = I_{xx} + I_{yy}$$

$$I_{xx} = 200 \times t_e \left(\frac{300}{2}\right)^2 \times 2 + \frac{t_e (300)^3}{12}$$

$$I_{yy} = 300 \times t_e (\bar{x})^2 + 2 \times \left[\frac{t_e \times (200)^3}{12} - (200 - \bar{x})^2 \times t_e \times 200 \right]$$

~~Q12~~ ~~12345678901234~~

$$J = I_{xx} + I_{yy} = 1.4297 \times 10^7 t_e$$

$$\tau_T = \frac{T r}{J} = \frac{36.429 \times 10^6 \times 207.14}{1.4297 \times 10^7 t_e} = \frac{527.79}{t_e} \text{ MPa}$$

$$\Rightarrow f_r = \sqrt{f_d^2 + f_T^2 + 2 f_d f_T \cos \theta}$$

$$\cos \theta = \frac{200 - \bar{x}}{r} = 0.689$$



$$f_r = \frac{693.15}{t_e} \text{ MPa} \leq \frac{f_y}{\sqrt{3} \gamma_{mw}} = \frac{410}{\sqrt{3} \times 1.25}$$

$$t_e \geq 366 \text{ mm}$$

$$k_s \geq 366 \text{ mm}$$

$$S \geq 5.23 \text{ mm}$$

Case-(ii) When Fillet Weld subjected to Direct load + BM



$$\text{Direct shear } (f_s) = \frac{P}{2l t_e}$$

$$\begin{aligned} \text{Bending stress } (f_b) &= \frac{M \cdot y}{I} \\ &= \frac{P e}{2 \times t_e l^3 \left(\frac{1}{2} \right)} \end{aligned}$$



$$\text{Resultant stress} = \sqrt{f_b^2 + 3 f_s^2}$$

and for safety:

$$\sqrt{f_b^2 + 3 f_s^2} \leq \frac{f_u}{\sqrt{3} \gamma_{mw}}$$

NOTE check for combination of stresses need not be considered for fillet Weld and Sum of Normal stress and shear stress $\leq \frac{f_u}{\sqrt{3} \gamma_{mw}}$

Que Stup of ISHB200 is welded to the column flange of ISHB 400 using fillet welds. The weld connecting the flange has size double of the weld connecting the web of ISHB 200 with the column flange. length of weld connecting the flange is 100 mm and that connecting the web is 150 mm. The Stup carries a factored load of 250 kN @ eccentricity of 200 mm. Determine the size of weld for safety of the connection Assuming Shop Welding, Fe410



$$\text{stress due to direct load} = f_s = \frac{P_u \rightarrow 250 \times 10^3}{(2 \times 100 \times 2t_e + 2 \times 150 \times t_e)}$$

$$f_s = \frac{357.14}{t_e} \text{ MPa}$$

$$\text{Stress due to BM } f_b = \frac{M \cdot y}{I}$$

$$I = 2 \left[\frac{t_e \times (150)^3}{12} \right] + 2 \times \left[100 \times 2t_e \times \left(\frac{200}{2} \right)^2 \right]$$

$$I = 4.56 \times 10^6 t_e$$

$$f_b = \frac{250 \times 10^3 \times 200}{4.56 \times 10^6} \times \frac{200}{2} = \frac{1096.5}{t_e} \text{ MPa}$$

$$f_r = \sqrt{f_b^2 + 3f_s^2}$$

$$f_r = \sqrt{\left(\frac{1096.5}{t_e} \right)^2 + 3 \times \left(\frac{357.14}{t_e} \right)^2}$$

$$f_r = \frac{1258.95}{t_e} \text{ MPa}$$



$$\text{for safety } \frac{1258.95}{t_e} \leq \frac{f_u \rightarrow 410}{\sqrt{3} \gamma_{mw} \rightarrow 1.25}$$

$$t_e \geq 6.648 \text{ mm}$$

$$b_{fs} \geq 6.648$$

$$\boxed{S \geq 9.49 \text{ mm}}$$

case(iii) Butt weld subjected to Direct load & BM



stress due to direct force, $f_s = \frac{P_u}{l t_e}$

stress due to bending moment = $\frac{M}{I} \cdot y$
(f_b)

$$f_b = \frac{P_u \cdot e}{\frac{t_e \cdot l^3}{12}} \quad (1/2)$$

$$f_r = \sqrt{f_b^2 + 3f_s^2}$$


for safety $f_r \leq \frac{f_y}{\gamma_{mw}}$

However γ_{mw} in design.

For design of bracket connection subjected to bending and shear, the weld depth can be assumed slightly higher than that calculated by considering stress due to bending only.

Finally Safety shall be ensured for the combination of stress.

Que:



Stress due to 'P'

$$f_{s1} = \frac{P}{\pi D t e}$$

stress due to torsion

$$f_{s2} = \frac{T \cdot D/2}{\pi D t e (D/2)^2}$$

$$f_s = \sqrt{f_{s1}^2 + f_{s2}^2}$$

$$f_b = \frac{M \cdot y}{I} = \frac{P e \cdot D/2}{\frac{1}{2} [\pi D t e (D/2)^2]} \quad \left\{ I = J/2 \right.$$

TENSION MEMBERS

Member subjected to Axial tension is called tension member or tie bar.

Tension member may fail in following modes.

- i) Gross section yielding
- ii) Net section Rupture
- iii) Block shear failure

Design strength of Tension member

① For Gross-section yielding

$$T_{dg} = \frac{f_y}{\gamma_{m0}} \cdot A_g$$

$A_g \rightarrow$ gross secⁿ Area
 $\gamma_{m0} \rightarrow 1.1$ (yielding)


② Net-section Rupture

A) for plate and Flats

$$T_{dn} = \frac{0.9 f_u}{\gamma_{m1}} \cdot A_n$$

$A_n \rightarrow$ net secⁿ Area
 $\gamma_{m1} \rightarrow 1.25$
(Rupture)

B) for Angles



In case of Angles, We've connected leg and outstanding leg. force is transferred from gusset to the connected leg and this force gets transferred as tensile stress over the entire c/c,

At the joint if the length of connection is small connected leg will have higher stress than the outstanding leg, Thus stress in outstanding leg, lags behind the stress in the connected leg. And this phenomenon is called shear lag. Due to shear lag effectiveness of the outstanding leg will be less and hence in case of angles, it is better to adopt connection through longer leg. We prefer unequal angles in case of tension members.

$$T_{dn} = \frac{0.9 f_u}{\gamma_{m1}} A_{nc} + \beta \cdot \frac{f_y}{\gamma_{m0}} \cdot A_{go}$$

$$\beta = 1.4 - 0.076 \frac{w}{t} \frac{f_y}{f_u} \cdot \frac{b_s}{l_c} \quad \checkmark$$



$$\beta \geq 0.7 \text{ and } \beta \leq \frac{0.9 f_u / \gamma_{m1}}{f_y / \gamma_{m0}} \quad \checkmark$$

$w \rightarrow$ length of outstanding leg


$t \rightarrow$ thickness of member

$b_s \rightarrow$ shear lag width and it is measured from the farthest point on the outstanding leg to the nearest line of bolt or weld in the connected leg along the center line

$l_c \rightarrow$ length of connection i.e c-c distance b/w extreme bolts in dirⁿ of force




$$b_s = w + g - t$$





$$b_s = w$$

for channels



$$t = t_f$$



$$A_{g0} = (b_1 - \frac{t}{2}) \times t$$

$$A_{nc(1-1)} = (b_2 - \frac{t}{2}) \times t - d_0 \times t$$

$$A_{nc(2-2)} = (b_2 - \frac{t}{2}) \times t - 2d_0 \times t + \frac{P^2}{4g} \times t$$

$$A_{nc} = \min(A_{nc1}, A_{nc2})$$

$$A_{g0} = (b_1 - \frac{t}{2}) \times t$$

NOTE Increasing the length of connection will reduce the shear lag effect.

* The formula for T_{dn} can't be used to calculate the net area of the secⁿ required in the start of design because it contains variables like b_s , w , t & e_c etc. which will not be known unless the section is finalised.

Therefore for primary design the Rupture strength can be calculated by using following formula.

$$\rightarrow T_{dn} = \frac{\alpha f_u}{\gamma_{m1}} A_n$$

A_n = Net Area
of the Angle secⁿ

$\alpha = 0.6$ for 1 or 2 bolts.

$\alpha = 0.7$ for 3 bolts.


$\alpha = 0.8$ for ≥ 4 bolts.

$\alpha = 0.8$ for Welding.

α is higher for higher no. of bolts because l_e will be more.


③ Block shear Failure

In case of Welding $A_{tn} = A_{tg}$ and $A_{vn} = A_{vg}$
i.e. consider failure of gusset plate




slenderness ratio

$$\lambda_{\max} = \frac{l_{\text{eff}}}{r_{\min}}, \quad r_{\min} = \sqrt{\frac{I_{\min}}{A}}$$



There is no buckling or stability problem in case of tension member. However, tension member may be subjected to compression in load reversal or during transportation or erection.

Hence to safeguard against this, Max. slenderness ratio is restricted.



Description

Max^m slenderness

- ① A Tension member in which reversal of direct stress due to other than wind / EQ
- ② Members normally acting as a tie but in which reversal of loading is due to Wind / EQ (like tie member in a truss)

180

350


Description

max: 1

- ③ Members always under tension except pretension member


400

③



if secⁿ is having atleast one axis of symmetry then that axis and an axis $\perp$ to it passing through the secⁿ can be minor Axis.

Effective length




Lug Angle

Lug Angle

Gusset

Main Angle



$$F_{\text{outstanding}} = \frac{F \cdot A_{\text{outstanding}}}{A_{\text{total}}}$$

Bolts ① → Main member + Gusset

Bolts ② → outstanding leg of Main member + outstanding leg of Lug angle

Bolts ③ → lug angle + Gusset

lug angle is provided to reduce the length of connection and also to eliminate shear lag effect

for connection to be efficient. bolt connecting the outstanding leg of ~~main~~ main member with lug Angle should start in advance of all other bolts. This will ensure that force gets efficiently transferred from the outstanding leg to the lug Angle.

The main member will be assume to have no shear lag effect because both the legs will be treated as connected legs.

Tensile strength of main member along the Min. Net secⁿ shall be checked.

Min. no of bolts connecting the lug angle with the gusset plate ≥ 2


When Angle is the Main Member

- ① lug angle and it's connection with the Gusset plate should be design for a force ≥ 1.2 times the force in the outstanding leg. (bolt Group-3)
- ② connection of outstanding leg of Main member with lug angle should be designed for a force ≥ 1.4 times the force in the outstanding leg of Main member (Bolt Group-2)

When channel is the main member

lug angles and their connections with Gusset plate should be designed for a force $\geq 1.1 \times F_{\text{outstanding}}$

Connection of outstanding legs of main member with the lug angle should be design for a force $\geq 1.2 \times F_{\text{outstanding}}$



Design steps

①. $A_{\text{net}} = \frac{T_u}{\frac{\alpha F_u}{\gamma_{m1}}}$

calculate
Net Area req.

② increase A_n by 20-40% to obtain Gross Area

③ consider a section and check for gross yielding and Slenderness Ratio

$$T_u \leq \frac{A_g f_y}{\gamma_{m0}}$$

$$\Rightarrow A_g \geq \frac{T_u}{f_y / \gamma_{m0}}$$

$$\lambda_{\text{max}} = \frac{l_{\text{eff}}}{\gamma_{\text{min}}} > \lambda_{\text{recommended}}$$

④ design connection and check for net section rupture and block shear failure

NOTE 2 - lines of bolts can be provided on 1 leg of angle only when the connected leg length is ≥ 125 mm
 - 2 lines of bolts can be provided on the web of a channel only when depth of channel ≥ 150 mm.
 In case of angles as tension member, prefer to connect longer leg in case of unequal angle to minimize the shear lag effect

Q.4. Design a bridge-truss diagonal subjected to $T_d = 300$ kN, length of diagonal = 3m, the tension member is connected to a gusset plate of 16 mm thickness using 2-lines of 20mm dia bolt of grade 4.6, steel section is Fe 410 grade and available sec are - ISA 125X95X8, Area = 17 cm²

$$C_{xx} = 3.8 \text{ cm}, C_{yy} = 2.32 \text{ cm}$$

$$Y_{uu} = 4.41 \text{ cm}, Y_{vv} = 2.05 \text{ cm}$$

$$Y_{xx} = 3.97 \text{ cm}, Y_{yy} = 2.81 \text{ cm}$$

$$\text{ISA } 150 \times 115 \times 10, \text{ Area} = 25.7 \text{ cm}^2, C_{xx} = 4.57 \text{ cm}$$

$$C_{yy} = 2.84 \text{ cm}, Y_{uu} = 5.31 \text{ cm}, Y_{vv} = 2.48 \text{ cm}$$

$$Y_{xx} = 4.76 \text{ cm}, Y_{yy} = 3.41 \text{ cm}$$

considering more than 4 no. of bolts $\phi = 0.8$

$$\text{Net Area} = \frac{T_d}{\phi f_u / \gamma_m} = \frac{300 \times 10^3}{0.8 \times 410 / 1.25} = 1143.29 \text{ mm}^2$$

$$\text{Consider } A_g = A_n \times 1.2$$

$$A_g = 1371.95 \text{ mm}^2$$

$$\text{ISA } 125 \times 95 \times 8, \text{ Area} = 1700 \text{ mm}^2$$


$$\text{consider } \text{ISA } 125 \times 95 \times 8$$

$$A_{g, req.} = \frac{T_u}{f_y / \gamma_{mo}} = \frac{300 \times 10^3}{250 / 1.1} = 1320 \text{ mm}^2 < A_{g, provided.} \quad \underline{\underline{O.K}}$$

$$\lambda_{max} = \frac{l_{eff}}{\gamma_{min}} = \frac{Kl}{\gamma_{min}} = \frac{1 \times 3 \times 10^3 \text{ mm}}{\gamma_{min}} = \underline{\underline{O.K}}$$

in case of single angle member take $l_{eff} = l$
(No recommendation given in IS 800:2007)

$$\lambda_{max} = \frac{1 \times 3 \times 10^3}{2.05 \times 10} = 146.34 < 180 \quad \underline{\underline{O.K}}$$



Bolt is in single shear

$$V_{dsb} = 45.27 \text{ kN}$$


$$V_{dpb} = \frac{2.5 k_b d t f_u}{\gamma_{mb}} = \frac{2.5 \times 0.5 \times 20 \times 8 \times 410}{1.25} = 65.60 \text{ kN}$$

$$V_{db} = 45.27 \text{ kN}$$

$$k_b = \min \left\{ \frac{e}{3d_0}, \frac{p}{3d_0} - 0.25, \frac{f_{ub}}{f_u}, 1 \right\}$$

$$\text{No. of bolts req.} = \frac{T_u}{V_{db}} = \frac{300}{45.27} = 6.62$$

provide 7 no. of bolts.



$$\text{Pitch} = 2.5 d_o = 2.5 \times 20 = 50 \text{ mm}$$

$$\text{Gauge} = 2.5 d = 50 \text{ mm}$$

Considering shear lag effect

$$T_{dn} = \frac{0.9 f_u}{\gamma_{m1}} A_{nc} + \beta \frac{f_y}{\gamma_{m0}} A_{go}$$

$$\beta = 1.4 - 0.076 \frac{w f_y}{t F_u} \cdot \frac{b_s}{l_c}$$

$$\beta \geq 0.7, \quad \beta \leq \left(\frac{0.9 f_u / \gamma_{m1}}{f_y / \gamma_{m0}} \right)$$


$$\begin{aligned}
 b_s &= w + g - t \\
 &= 95 + 40 - 8 \\
 &= 127 \text{ mm}
 \end{aligned}$$

$$\beta = 1.4 - 0.076 \times \frac{95}{8} \times \frac{250}{410} \times \frac{127}{300 \text{ mm}} \quad \left\{ \begin{array}{l} 50 \times 6 \end{array} \right.$$

$$\beta = 1.167 \geq 0.7$$

$$\beta \leq \left(\frac{0.9 \times 410 / 1.25}{250 / 1.1} \right) = 1.298$$

$$\beta = 1.167$$



$$A_{g0} = (95 - 8/2) \times 8 = 728 \text{ mm}^2$$

$$\begin{aligned} A_{nc} &= (125 - 8/2) \times 8 - d_o t \\ (1-1) &= (125 - 4) \times 8 - 22 \times 8 \\ &= 792 \text{ mm}^2 \end{aligned}$$

$$\begin{aligned} A_{nc} &= (125 - \frac{8}{2}) \times 8 - 2d_o t + \frac{p^2}{4g} t \\ &= 121 \times 8 - 2 \times 22 \times 8 + \frac{50^2}{4 \times 50} \times 8 \\ &= 716 \text{ mm}^2 \end{aligned}$$

$$\Rightarrow A_{nc} = \min(762, 716)$$

$$A_{nc} = 716 \text{ mm}^2$$

$$T_{dn} = \frac{0.9 f_u}{\gamma_{m1}} A_{nc} + \frac{\beta f_y}{\gamma_{m0}} \times A_{g0}$$

$$\begin{aligned} T_{dn} &= \frac{0.9 \times 410}{1.25} \times 716 + \frac{1.167 \times 250}{1.1} \times 728 \\ &= 404 \text{ kN} > 300 \text{ kN} \quad \underline{\underline{\text{O.K}}} \end{aligned}$$

Block shear failure

$$A_{vg} = 8 \times (35 + 50 \times 6) = 2680 \text{ mm}^2$$

$$A_{dn} = 8 \times (35 + 50 - \frac{22}{2}) = 592 \text{ mm}^2$$

$$T_{db1} = \frac{f_y}{\sqrt{3} \gamma_{m0}} A_{vg} + \frac{0.9 f_u}{\gamma_{m1}} A_{tn}$$

$$T_{db1} = \frac{250 \times 2680}{\sqrt{3} \times 1.1} + \frac{0.9 \times 410}{1.25} \times 592$$

$$T_{db1} = 526.41 \text{ kN}$$

$$T_{db2} = \frac{0.9 f_u}{\sqrt{3} \gamma_{m1}} A_{vn} + \frac{f_y}{\gamma_{m0}} A_{tg} \quad \left\{ \begin{array}{l} A_{vn} = \\ A_{tg} = \end{array} \right.$$

~~T_{db2}~~


$$A_{vn} = (35 + 6 \times 50 - 3.5 \times 22) \times 8$$

$$= 2064 \text{ mm}^2$$

$$A_{tg} = 85 \times 8 = 680 \text{ mm}^2$$

$$T_{db2} = 506.32 \text{ kN} > 300 \text{ kN}$$

Que An ISA 100x75x10 is used as a tension member with longer leg connected to 20 mm thick gusset plate the member carries a factored load of 350 kN. Connection has been done with lug angle, the bolt is M20 of grade 4.6 and steel Fe410. Design the connection if the available sec^s for lug angle are 100x75x6, 75x75x8 and 100x75x8



Member shall be designed as already given in the Que.

$$F_{\text{outstanding}} = \frac{F}{A_{\text{total}}} \times A_{\text{outstanding}}$$
$$= \frac{350}{(100+75-10) \times 10} \times (75-10/2) \times 10 = 148.4 \text{ kN}$$

M20 bolt of grade 4.6

$$V_{db} = 45.27 \text{ kN}$$

$$V_{dpb} = \frac{2.5 K_b d t f_u}{\gamma_{mb}} = \frac{2.5 \times 0.5 \times 20 \times 6 \times 410}{1.25} = 49.20 \text{ kN}$$

$$V_{db} = 45.27 \text{ kN}$$

Considering 6mm thickness of lug angle also the bearing strength of bolt = 49.20 kN

$\Rightarrow$ bolt value = 45.27 kN

no. of bolts req. to connect both the outstanding

$$\text{legs} = \frac{1.4 \times 148.4}{45.27} = 4.58 \approx 5 \text{ bolts}$$

no. of bolts req. to connect Gussset plate with

$$\text{lug angle} = \frac{1.2 \times 148.4}{45.27} = 3.39 \approx 4 \text{ bolts}$$

lug angle shall be designed for a force of $1.2 \times 148.4 = 178.08 \text{ kN}$

$$\text{Net area of lug angle req.} = \frac{178.08}{0.9 f_u / \gamma_{m1}} = 603 \text{ mm}^2$$

(No shear lag effect in lug angle)

consider Gross Area of lug angle as $= 1.2 \times 603$
 $= 723.6 \text{ mm}^2$

100x75x6
 $A = (100 + 75 - 6) \times 6 = 1014 \text{ mm}^2$


75x75x8

$A = (75 + 75 - 8) \times 8 = 1136 \text{ mm}^2$

consider angle section 100x75x6 mm.

Net secⁿ rupture for lug angle :—

Lug Angle



$$A_{nc(1-1)} = (169 - 22) \times 6 = 882 \text{ mm}^2$$

$$A_{nc(2-2)} = \left(169 - 2 \times 22 + \frac{P^2}{4g} \right) \times t \quad a$$

$$= \left(169 - 44 + \frac{100^2}{4 \times 9.8} \right) \times 6 = 901.55 \text{ mm}^2$$

$$A_{nc(3-3)} = \left(169 - 2 \times 22 + \frac{P^2}{4g} \right) \times t$$

$$= \left(169 - 44 + \frac{50^2}{4 \times 9.8} \right) \times 6 = 787.86 \text{ mm}^2$$

COMPRESSION MEMBER

A structural member which is straight and subjected to axial compressive force only with no initial imperfection is called as a ~~can~~ ideal compression member.

Type of compression Member

- 1) column or stanchion
- 2) Strut $\rightarrow$ Used in roof ~~strut~~ trusses and bracing system.
- 3) boom of a crane

Classification of C/s

A plate element of a C/s may buckle locally due to compressive stress. This local buckling can be avoided before the limit state is achieved by limiting width to thickness ratio of each element of C/s subjected to axial force, Bm or shear.


When plastic analysis is used, secⁿ should be capable of forming plastic hinge without local buckling.

If Elastic analysis is used, Member should be capable of developing ~~the~~ yield stress before local buckling.

As per IS 800:2007, Based on local buckling the C/s available are:-


- i) plastic secⁿ (class-1)
- ii) Compact secⁿ (class-2)
- iii) semi-compact secⁿ (class-3)
- iv) slender secⁿ

① plastic section secⁿ which develops full plastic moment capacity and has significant rotational capacity req^d for failure of structure by formation of plastic hinge i.e. before collapse mechanism local buckling doesn't occur ($\theta_2 > 6\theta_1$)




$\theta_2 \rightarrow$ lower limit of rotation for plastic secⁿ
 $\theta_1 \rightarrow$ Rotation @ onset of plasticity.


② compact section The c/s which can develop plastic hinge but has inadequate plastic hinge rotation capacity for formation of plastic mechanism due to local buckling ($\theta_2 < 6\theta_1$)



③ semi-compact section section which can develop yield stress @ extreme fibre and can't develop plastic hinge due to local buckling



④ slender secⁿ secⁿ in which local buckling occurs even before extreme fibre reaching the stress of f_y .








As per IS 800-2007

$$\epsilon = \sqrt{\frac{250}{f_y}}$$

As per IS 800:2007

		Ratio	Plastic	compact	semi-compact
Outstanding element of	Rolled sec ⁿ	b/t_f	9.4ϵ	10.5ϵ	15.7ϵ
Comp. flange	Welded sec ⁿ	b/t_f	8.4ϵ	9.4ϵ	13.6ϵ
Internal element of comp. flange	Comp. due to Bending	b/t_f	29.3ϵ	33.5ϵ	42ϵ
	Axial Comp.	b/t_f	Not Applicable		42ϵ
Web of I-sec ⁿ	When N.A @ Mid depth	d/t_w	84ϵ	105ϵ	126ϵ
	Axial Comp.	d/t_w	Not Applicable		42ϵ






for the above secⁿ to be plastic secⁿ mark the max. permissible width of internal and outstanding elements.

NOTE @ When diffⁿ elements of a cls for under diffⁿ classes, overall secⁿ shall be classified as governed by the lowest class.

@ In comp. Member, for Plastic, compact & semi-compact secⁿ, the effective sectional Area (A_e) is the gross Area. However if holes are not filled up, deduction shall be made for this.

for slender secⁿ, the effective area is calculated by deducting the width of comp. plate in excess of Semi-compact secⁿ

Ques. Find A_e for the following Axial comp. member
Take $f_y = 250 \text{ mpa}$



$$\frac{b_o}{t_f} = 13.6 \epsilon$$

$$\epsilon = \sqrt{250/150} = 1$$

$$b_o = 13.6 \epsilon t_f = 13.6 \times 1 \times 6 = 81.6 \text{ mm}$$

$$\frac{d}{t_w} = 42 \epsilon$$

$$d = 42 \epsilon t_w = 252 \text{ mm}$$

$$A_e = 4 \times 81.6 \times 6 + 2 \times 6 \times 6 + 252 \times 6 = 3542.4 \text{ mm}^2$$


Area shall be neglected from such a locⁿ that we get a min inertia.

possible failure mode in comp. member


- (i) squashing When length is relatively small (stocky columns) and it's component ~~plated~~ plate elements are prevented from local buckling. Column will be able to attain it's full strength.

$$P_d = \frac{f_y}{\gamma_{m0}} \times A_e$$

ii) local buckling failure may occur in the plate elements like flange or web due to buckling with no overall deflection of the member $\perp$ to the applied load, local buckling can be prevented by limiting the width to thickness ratio of the plate element.




iii) Overall flexural buckling. In this case, failure of member occurs by excessive deflection about weaker principle axis.





As λ value $\uparrow$, load carrying capacity $\downarrow$

iv) Torsional buckling



- Torsional buckling failure occurs by twisting about shear center i.e twisting about longitudinal axis
- Torsional buckling is a possible mode of failure for point symmetric secⁿ and it can only properly occur when the shear center and centroid of c/s coincides.

v) Flexural Torsional buckling



- it is caused by a combination of flexural and torsional buckling. the member bends as well as twists, it occurs only in unsymmetrical sec and singly symmetrical sec

- Doubly symmetric sec ain't subjected to flexural torsional buckling.


Determination of slenderness ratio

$$\lambda = \frac{l_{eff}}{r}$$

$$r = \sqrt{\frac{I}{A}}$$

for same l_{eff} about both the Axis $\lambda = \frac{l_{eff}}{r_{min}}$

- l_{eff} depends on support cond.
- if the sec is having at least one axis of symmetry then that axis or an axis $\perp$ to symmetrical axis and passing through C.G. will be minor principle axis




$$I_{xx, comb} = 2 I_{xx, one}$$

$$I_{yy, comb} = 2 \times \left[I_{yy, one} + A_{one} \left(C_{yy} + \frac{t}{2} \right)^2 \right]$$

$\lambda \nless \lambda_{max}$ recommended by IS code

Type	λ_{max}
i) comp. member carrying load due to DL + LL	180
ii) comp. carrying load due to WL / EQ only	250
iii) Member normally acting as tie in a roof truss or bracing system but subjected to possible reversal due to action of Wind / EQ	350



Column strength

$$P_{cr} = \frac{\pi^2 EI}{l_{eff}^2}$$


$$f_{cr} = \frac{\pi^2 E}{\lambda^2}$$

Common hot rolled secⁿ and built up steel member used to carry axial comp. usually fail by flexural buckling or flexural torsional buckling

The buckling strength of this member is affected by

- residual stress
- initial bow
- accidental eccentricity

To account for these factors large number of tests were carried out and column buckling curve a, b, c, d were established. These a, b, c, d are called buckling class.



This curve is based on Perry - Robertson formula.

f_{cd} of axially loaded column is given by -

$$P_d = f_{cd} A_e$$

f_{cd} is design comp. stress.

class - a $\rightarrow$ safe with least imperfection *

class - b $\rightarrow$ safe with med^m imperfection ✓

class - c $\rightarrow$ safe with lot of imperfection

class - d $\rightarrow$ safe with Max^m imperfection

Calculation of f_{cd} for flexural Buckling

• Axially loaded comp. member

$$f_{cd} = \frac{f_y / \gamma_{m0}}{\phi + \sqrt{\phi^2 - \lambda_e}} = \chi \frac{f_y}{\gamma_{m0}} \leq \frac{f_y}{\gamma_{m0}}$$

$\chi \rightarrow$ strength reduction factor

$$\phi = 0.5 [1 + \alpha(\lambda_e - 0.2) + \lambda_e^2]$$

$\lambda_e \rightarrow$ non-dimensional effective slenderness ratio

$$\lambda_e = \sqrt{\frac{f_y}{f_{cc}}} = \sqrt{\frac{f_y L^2}{\pi^2 E}} = \sqrt{\frac{f_y}{\pi^2 E}} \cdot L$$

$f_{cc} \rightarrow$ Euler's buckling stress

$\alpha \rightarrow$ imperfection factor based on buckling class

NOTE if $\lambda_e < 0.2$, then the column can achieve full plastic resistance i.e. buckling eff. can be neglected.

Buckling class as per IS 800-2007.

Rolled Angle, channel secⁿ, T secⁿ, solid secⁿ (Plat, flats etc)

$\downarrow$
Buckling class - C


Build-up member $\rightarrow$ Buckling class - B

Hollow secⁿ (Hot rolled) $\rightarrow$ A


Hollow secⁿ (Cold rolled) $\rightarrow$ B

Rolled-I secⁿ can be A, B or C

Limit	Buckling about	Buckling class.
$\frac{h}{b_f} > 1.2$	Z-Z	a
and $L_f \leq 40mm$	Y-Y	b
$\frac{h}{b_f} > 1.2$ and	Z-Z	b
$40 < t_f < 100 mm.$	Y-Y	c



Que Calculate the design comp. load that can be carried by the secⁿ shown in the figure if the $L_{eff} = 5.5 m$
Fe410



ISM C 400

$$\begin{aligned} d &= 400 \text{ mm} & A &= 6293 \text{ mm}^2 & b_f &= 100 \text{ mm} & t_f &= 15.3 \text{ mm} \\ t_w &= 8.6 \text{ mm} & I_{zz} &= 15.083 \times 10^7 \text{ mm}^4 & I_{yy} &= 0.5048 \times 10^7 \text{ mm}^4 \\ g &= 60 \text{ mm} & C_{yy} &= 24.2 \text{ mm} \end{aligned}$$

Design comp. load $P_d = f_{cd} A_e$

$$b_i = 420 \text{ mm}$$

$$b_o = 40 \text{ mm}$$

$$b_o = 100 \text{ mm}$$

$$\frac{b_f}{t_f} \leq 42 \epsilon \Rightarrow b_i \leq 42 \times 1 \times 16$$
$$b_i \leq 672 \text{ mm}$$

$$\underline{\epsilon = 1} \quad \Rightarrow \text{OK}$$

$$\frac{b_o}{t_f} \leq 15.7 \epsilon_o \phi$$

$$b_o \leq 15.7 \times 1 \times 15.3 = 240.21 \text{ mm} > b_f (100 \text{ mm})$$

We can consider all the area of C/S as the secⁿ can be classified as semi-compact or better than that.

Total eff. Area :-

$$A_e = 2 \times 6293 + 16 \times 500 = 20586 \text{ mm}^2$$

$$f_{cd} = \frac{f_y}{\gamma_{m0}}$$


$$\phi + \sqrt{\phi^2 - \lambda_e^2}$$

$$\phi = 0.5 [1 + \alpha (\lambda_e - 0.2) + \lambda_e^2]$$

$$\lambda_e = \sqrt{\frac{f_y}{\pi^2 E}} \cdot l \quad , \quad \alpha = 0.49$$

$$\lambda_{\max} = \frac{l_{\text{eff}}}{\gamma_{\min}}$$

$$\gamma_{\min} = \sqrt{\frac{I_{\min}}{A}}$$



$$\bar{Y} = \frac{16 \times 500 \times \frac{16}{2} + 2 \times 6293 \times (16 + \frac{400}{2})}{16 \times 500 + 2 \times 6293}$$

$$\bar{Y} = 135.17 \text{ mm.}$$

$$I_{xx} = \frac{16 \times 500^3}{12} + 2 \times \left[I_{yy} + A_{one} (y_y + \frac{300}{2})^2 \right]$$

$\nearrow 0.5048 \times 10^7$ $\nearrow 6293$ $\nearrow 24.2$

$$I_{xx} = 55.869 \times 10^7 \text{ mm}^4$$

$$I_{yy} = \frac{500 \times 16^3}{12} + 500 \times 16 \times (135.17 - \frac{16}{2})^2$$

$$+ 2 \left[I_{zz,one} + A_{one} (216 - 135.17)^2 \right]$$

$\nearrow 6293$
 $\downarrow 15.083$

$$I_{yy} = 51.35 \times 10^7 \text{ mm}^4$$

$$I_{min} = 51.35 \times 10^7$$

$$r_{max} = \frac{I_{eff}}{I_{min}} = \frac{5.5 \times 10^3}{\frac{51.35 \times 10^7}{20586}} = 34.82$$

$$\lambda_e = \sqrt{\frac{f_y}{\pi^2 E}} \cdot \lambda = 309.0392$$

$$\phi = 0.5 (1 + \alpha (\lambda_e - 0.2) + \lambda_e^2)$$

$$\phi = 0.5 (1 + 0.49 (0.392 - 0.2) + 0.392^2)$$



$$\phi = 0.62$$

$$f_{cd} = \frac{f_y / \gamma_{m0}}{\phi + \sqrt{\phi^2 - \lambda_e^2}} = \frac{250 / 1.1}{0.62 + \sqrt{0.62^2 - 0.392^2}}$$


$$f_{cd} = 206.54 \text{ MPa}$$

$$P_d = f_{cd} \times A_e = 206.54 \times 20586 = 4251.83 \text{ kN}$$



Angle struts



(A) continuous angle strut



(B) Discontinuous angle strut



Single Angle strut comp in single angle strut may be transfered either concentrically or eccentrically by connecting only one leg to Gusset plate

Concentric loading → in case of concentric loading (Gusset on both legs) for single and fed shall be calculated considering flexural buckling using buckling class C

Eccentric loading → for single angle loaded eccentrically i.e connection through one leg only we need to consider flexural torsional buckling. in case of flexural torsional buckling


$$\lambda_e = \sqrt{K_1 + K_2 \lambda_{vv}^2 + K_3 \lambda_{\phi}^2}$$

K_1, K_2 and K_3 are constant depending on end cond.

∅

$$\lambda_{vv} = \frac{l / r_{vv}}{\sqrt{\frac{\pi^2 E}{250}}}$$


$$\lambda_{\phi} = \frac{\frac{b_1 + b_2}{2t}}{\sqrt{\frac{\pi^2 E}{250}}}$$



$$\lambda_{vv} = \frac{l}{r_{vv}} = \frac{l}{\sqrt{\frac{\pi^2 E}{f_y}}}$$

$$\lambda_{\phi} = \frac{\left(\frac{b_1 + b_2}{2t} \right)}{\sqrt{\frac{\pi^2 E}{f_y}}}$$

$l \rightarrow$ c/c distance of supporting member and take $l_{eff} = l$



Values of K_1 , K_2 and K_3

No. of bolts at each end connection	Gusset/connecting member fixity/rigidity	K_1	K_2	K_3
≥ 2	fixed	0.2	0.35	20
	Hinged	0.7	0.6	5
1	Fixed	0.75	0.35	20
	Hinge.	1.25	0.5	60

in case of welded connection K_1 , K_2 and K_3 shall be consider for Fixed cond. with > 2 bolt

Double Angle discontinuous strut


A) connected on opposite side of Gusset

In this case λ_{eff} shall be calculated by using flexural buckling.

Connection shall be by not less than 2 bolts or rivets in line along the angles @ each end or by equivalent welding.

λ_{eff} shall be taken as follows:—

- for buckling in plane of truss $\rightarrow 0.7 - 0.85 \lambda$
 - Buckling out of plane of truss $\rightarrow \lambda$
- $\lambda \rightarrow C/c$ distance b/w connection.



$$\lambda_e = \sqrt{\frac{f_y}{\pi^2 E}} \lambda$$

$\downarrow$
 $\max(\lambda_{xx}, \lambda_{yy})$

$$\lambda = \frac{l}{r}$$

$$\lambda_{xx} = \frac{\lambda_{eff,xx}}{r_{xx}} = \frac{(0.70 - 0.85) l}{r_{xx}}$$

$$\lambda_{yy} = \frac{\lambda_{eff,yy}}{r_{yy}} = \frac{l}{r_{yy}}$$

$$Y_{xx, comb} = \sqrt{\frac{I_{xx, comb}}{A_{comb}}} = \sqrt{\frac{2 I_{xx, one}}{2 A_{one}}} = Y_{xx}$$


$$\gamma_{yy, \text{comb.}} = \sqrt{\frac{I_{yy, \text{comb.}}}{A_{\text{comb.}}}} = \sqrt{\frac{2 \left[I_{yy, \text{one}} + A_{\text{one}} \left(c_{yy} + \frac{t}{2} \right)^2 \right]}{2 A_{\text{one}}}}$$

$$= \sqrt{\gamma_{yy}^2 + \left(c_{yy} + \frac{t}{2} \right)^2}$$

B) connected on the same side of Gusset

in this case fcd shall be calculated considering Flexural torsional buckling. and treat the angle as single angle eccentrically loaded.

To calculate the total capacity, calculate capacity of one angle and multiply this by 2



$$\lambda_e = \sqrt{K_1 + K_2 \lambda_{vv}^2 + K_3 \lambda_{\phi}^2}$$

$$\lambda_{vv} = \frac{\lambda / r_{vv}}{\sqrt{\frac{\pi^2 E}{250}}}, \quad \lambda_{\phi} = \frac{\frac{b_1 + b_2}{2t}}{\sqrt{\frac{\pi^2 E}{250}}}$$

Continuous Double Angle

It shall be designed as axially loaded member

Considering flexural buckling

eff. length is taken as $(0.7-1) l$ in the plane
of truss and l out of plane

Que: calculate the strength of a discontinuous strut
of $l = 3.5 \text{ m}$, the strut consist of 2 unequal
angles $100 \times 75 \times 8$, use 10 mm thick gusset plate
Fe 410, properties of Angle secⁿ -

$$A = 13.4 \text{ cm}^2, C_{xx} = 3.14 \text{ cm}, C_{yy} = 1.8 \text{ cm}$$

$$r_{xx} = 3.14 \text{ cm}, r_{yy} = 2.1 \text{ cm}$$

$$r_{zz} = 3.48 \text{ cm}, r_{vv} = 1.59 \text{ cm}$$

calculate considering

A) two Angles connected on opposite side of gusset

b) two Angles connected on same side of gusset


$$l = 3.5 \text{ m}$$

$$100 \times 75 \times 8$$

$$\text{gusset} = 10 \text{ mm}$$

$$\text{Fe 410}$$

a)



longer leg connected.

consider Flexural buckling.

$$f_{cd} = \frac{f_y}{\gamma_{m0}}$$

$$\phi + \sqrt{\phi^2 - \lambda^2}$$

$$\lambda_e = \frac{f_y}{\sqrt{\frac{\pi^2 E}{250}}} \cdot \lambda_{max}$$

$$\phi = 0.5 [1 + \alpha (\lambda_e - 0.2) + \lambda_e^2]$$

$$\lambda_{xx} = \frac{\lambda_{eff,xx}}{\gamma_{xx,comb}} = \frac{0.851}{\gamma_{xx,one}} = \frac{0.85 \times 3.5 \times 10^2}{3.14} = 94.74$$

in the plane
of truss

$$\lambda_{yy} = \frac{\lambda_{eff,yy}}{\gamma_{yy,comb}} = \frac{3.5 \times 10^2}{\sqrt{2.18^2 + (1.87 + 1/2)^2}} = 108.69$$

out of plane

$$\lambda_e = \sqrt{\frac{f_y}{\pi^2 E}} \cdot \lambda_{max}$$

$$\lambda_e = \sqrt{\frac{250}{3.14^2 \times 2 \times 10^5}} \times 108.69$$

$$\lambda_e = 1.223$$

$$\phi = 0.5 [1 + 0.49 (1.223 - 0.2) + 1.223^2]$$


$$\phi = 1.498$$

$$f_{cd} = \frac{250/1.1}{1.498 + \sqrt{1.498^2 - 1.223^2}}$$

$$f_{cd} = 96.18 \text{ MPa}$$

$$\text{Design force} = f_{cd} \times A_e = 96.18 \times 2 \times 13.4 \times 10^2 = 257.76 \text{ kN}$$

b)




When the Angles are connected on same side we need to consider flexural torsional buckling

Alternative 1

considering single Angle @ a time

Capacity = 2 × Capacity of single angle

$$\lambda_e = \sqrt{K_1 + K_2 \lambda_{vv}^2 + K_3 \lambda_\phi^2}$$



$$\lambda_{vv} = \frac{3.5 \times 10^3}{15.9} = 2.478$$

$$\sqrt{\frac{\pi^2 E}{f_y}}$$

$$\lambda_\phi = \frac{\frac{b_1 + b_2}{2t}}{\sqrt{\frac{\pi^2 E}{f_y}}} = 0.123$$

Assuming fixed cond. and more than 2 bolts

$$K_1 = 0.2, K_2 = 0.35, K_3 = 2.0$$

$$\lambda_e = \sqrt{K_1 + K_2 \lambda_{ev}^2 + K_3 \lambda_\phi^2}$$

$$\lambda_e = \sqrt{0.2 + 0.35 \times 2.47^2 + 90 \times 0.123^2}$$

$$\lambda_e = 1.624$$

$$\phi = 0.5 \left[1 + \overset{0.49}{\alpha} (\lambda_e - 0.2) + \lambda_e^2 \right]$$

$$\phi = 2.167$$

$$f_{cd} = \frac{f_y / \gamma_{mo}}{\phi + \sqrt{\phi^2 - \lambda_e^2}} = \frac{250 / 1.1}{2.167 + \sqrt{2.167^2 - 1.624^2}}$$

$$= 63.10 \text{ MPa}$$

$$P_d = f_{cd} \times A_e$$

$$= 63.10 \times 2 \times 13.4 \times 10^2$$

$$= 169.10 \text{ kN}$$

Alternative-2

considering both the angles as single unit width flexural torsional buckling

$$\gamma_{xx, \text{comb.}} = \sqrt{\frac{I_{\text{comb}, xx}}{A_{\text{comb.}}}} = \sqrt{\frac{2 \times [I_{xx, \text{one}} + A_{\text{one}} \times C_{xx}^2]}{2 A_{\text{one}}}}$$

$$\gamma_{xx, \text{comb}} = \sqrt{\gamma_{xx, \text{one}}^2 + C_{xx}^2} = \sqrt{3.14^2 + 3.1^2} = 4.4124 \text{ cm}$$

$$\gamma_{yy, \text{comb.}} = \sqrt{\frac{2 I_{yy, \text{one}}}{2 A_{\text{one}}}} = \gamma_{yy, \text{one}} = 2.18 \text{ cm}$$

$$Y_{min} = 218 \text{ cm}.$$

$$\lambda_{vv} = \frac{l/y_{min}}{\sqrt{\frac{\pi^2 E}{250}}} = \frac{3.5 \times 10^3}{21.8} = 1.80$$

$$\sqrt{\frac{3.14^2 \times 2 \times 10^5}{250}}$$

$$\lambda_{\phi} = 0.123$$

$$\lambda_e = \sqrt{k_1 + k_2 \lambda_{vv}^2 + k_3 \lambda_{\phi}^2}$$

$$\lambda_e = \sqrt{0.2 + 0.35 \times 1.80^2 + 20 \times 0.123^2}$$

$$\lambda_e = 1.28$$

$$\phi = 0.5 [1 + \alpha (\lambda_e - 0.2) + \lambda_e^2]$$

$$\phi = 0.5 [1 + 0.49 (1.28 - 0.2) + 1.28^2]$$

$$\phi = 1.58$$

$$f_{cd} = \frac{f_y / \gamma_{mo}}{\phi + \sqrt{\phi^2 - \lambda_e^2}} = 90.66 \text{ mpa.}$$

$$P_d = f_{cd} \times A$$

$$= 90.66 \times 2 \times 13.4 \times 10^2$$

$$= 243.02 \text{ kN.}$$

Design of comp. Members

Design of comp. member is a trial and error procedure because to find out gross Area we require f_{cd} , However f_{cd} itself is dependent on λ . so we can't have a direct solⁿ and we need to adopt trial & Error -

Step-1 calculate factored load

Step-2 Assume f_{cd} b/w 0.4 - 0.6 f_y or we can consider λ using the following table based on experience

TYPE	λ
single Angle	100-150
Double Angle	80-120
single channel	90-110
Double channel	40-80
single I	80-150
Double I	30-60

Step-3 Assume secⁿ based on Gross Area calculated and find out λ of the assumed secⁿ

$\lambda <$ permissible value as per IS code

Step-4 calculate f_{cd} for considered secⁿ and find out load carrying capacity

if load carrying capacity $>$ factored load

$\Rightarrow$ secⁿ is safe

or else Consider a larger secⁿ or a diffⁿ arrangement

The load carrying capacity shall not be generally more than 5% of the factored load.

* comp member में shear lag की होता है But इसे पहले ही member Buckle हो जाएगा

Que Design a single angle strut to carry a factored load of 70 kN, length of strut is 3m b/w the intersection. it is connected to 12 mm thick gusset plate using M20 bolts. of property class 4.6
Fe410 $\rightarrow$ steel.

For flexural buckling.

λ	f_{cd} (MPa)	sec ⁿ available are.
70	152	ISA 80x50x8
80	136	$r_{vv} = 10.6 \text{ mm}$
90	121	$A = 978 \text{ mm}^2$
100	107	ISA 90x90x6
110	94.6	$r_{vv} = 17.5 \text{ mm}$
120	83.7	$A = 1050 \text{ mm}^2$
130	74.3	
140	66.2	
150	59.2	

$$P_u = 70 \text{ kN}, \quad l = 3 \text{ m}, \quad \text{gusset} = 12 \text{ mm}.$$

Either we can consider a particular λ for single angle strut and based on the f_{cd} , the angle secⁿ can be selected. Finally we need to ensure that the selected angle satisfies λ and strength criteria.

Or in exam cond. we can consider the smallest angle secⁿ and check the adequacy if not satisfied then select the next available secⁿ.

consider $\lambda = 120$ hence $f_{cd} = 83.7 \text{ MPa}$.

$$\text{gross Area req}^n \quad \frac{P_u}{f_{cd}} = \frac{70000}{83.7} = 836 \text{ mm}^2$$

Single Angle Tension member में unequal
 comp member में equal prefer होते हैं। λ_{vv} में
आपत्ति

let us consider ISA 80x50x8 with $A_g = 978 \text{ mm}^2$

$$\lambda_{\max} = \frac{l_{\text{eff}}}{r_{\min}} = \frac{3 \times 10^3}{10.6} = 283.01 > 180$$

hence not safe

consider ISA 90x90x6 with $A_g = 1050 \text{ mm}^2$

$$\lambda_{\max} = \frac{l_{\text{eff}}}{r_{\min}} = \frac{3 \times 10^3}{17.5} = 171.42 < 180$$

safe.

In case of comp. member given an option consider equal angle for single angle strut because for same cls area equal angle will have higher r_{vv} and higher fcd value

for single angle strut, we need to consider flexural torsional buckling.

$$\lambda_e = \sqrt{K_1 + K_2 \lambda_{vv}^2 + K_3 \lambda_\theta^2}$$

$$K_1 = 0.2, K_2 = 0.35, K_3 = 20$$

$$\lambda_{vv} = \frac{l}{r_{vv}} = \frac{3 \times 1000}{17.5} = 1.92$$

$$\sqrt{\frac{\pi^2 E}{f_y}} = \sqrt{\frac{3.14^2 \times 200000}{250}}$$

$$\lambda_\theta = \frac{(b_1 + b_2) / 2t}{\sqrt{\frac{\pi^2 E}{f_y}}} = \frac{(90 + 90) / 12}{\sqrt{\frac{3.14^2 \times 2 \times 10^5}{250}}} = 0.168$$

$$\lambda_e = 1.43$$

$$\phi = 0.5 (1 + \alpha (\lambda - 0.2) + \lambda^2)$$

$$\phi = 0.5 (1 + 0.49 (1.438 - 0.2) + 1.438^2)$$

$$\phi = 1.837$$

$$f_{cd} = \frac{f_y / \gamma_{m0}}{\phi + \sqrt{\phi^2 - \lambda^2}} = 76.26 \text{ MPa}$$


$$P_d = f_{cd} A_g$$

$$P_d = 76.26 \times 1050$$


$$P_d = 80.07 \text{ kN} > 70 \text{ kN}$$

O.K



Built-up Members Column




rolled secⁿ



lacing



lacing (lattice column)



End Batten
Intermediate Batten


Batten

When a large radius of gyration in z-diffⁿ dirⁿ or special shape is req^d we provide built up secⁿ can be with lacing (lattice column) or batten preferable when comp. load is less and eff. length is more


primary function of connecting system

- i) hold the ribs in place and equalise stress
- ii) points of intermediate support
- iii) not considered as axial load carrying element


Built up column with lacing




- for designing the column with lacing, we need to first design the column and decide the spacing b/w the ribs i.e before lacing design column design has to be completed
 - laced column is adopted in case of eccentrically loaded column and batten column is adopted in case of axially loaded column.
 - Rigidity of battened column is less than laced column
- Various types of lacing can be -
- i) single lacing intersecting
 - ii) single lacing non-intersecting
 - iii) Double lacing.



single lacing intersecting



single lacing non-intersecting



Double lacing


single lacing non-intersecting is preferred because failure of one intermediate connection won't lead to increase in the distance b/w intermediate connection significantly, hence chances of buckling of component column is less

permitted inclination of lacing with the longitudinal axis of column is $40^\circ - 70^\circ$; by increasing this angle we can reduce the value to C i.e height of component column even by increasing angle to 70° , if we are not able to prevent the chances of buckling of component column then we can provide double lacing.


At the top & bottom of laced column we provide battens called as end battens / tie plate

End batten ensures the balancing of unbalanced force in lacing, make the ends rigid and avoid distortion of end c/s

Generally r_{yy} should be slightly greater than r_{xx} for two channel or two I-secⁿ. This can be achieved by increasing the spacing ~~that~~ beyond that req^d for $r_{xx} = r_{yy}$. This will ensure that column doesn't buckle in plane of lacing.



- lacing should not be varied along the length of column i.e. r/s and angle of inclination shan't be varied along the length
- lacing on opposite faces should be mirror image and lacing on adjacent faces should be staggered.
To reduce the height of component column.
- cross members are not desirable in case of double lacing column i.e. lacing shan't be combined with batten o/w lacing will start ~~the~~ sharing axial load for which it has not been designed.



cross members
Not allowed!

Design Recommendations


- ① λ for laced column shall be taken 5% more than λ calculated using I_{eff} and r_{min}
 $\Rightarrow \lambda = \underline{1.05 \lambda_0}$
- ② The spacing b/w ribs in case of channel or I-secⁿ shall ensure $r_{yy} > r_{xx}$ ($\perp$ to lacing plane)

③ Angle of inclination of lacing with longitudinal axis of column shall be b/w $40^\circ - 70^\circ$ (for design purpose consider 45°)


④ The max. spacing b/w intermediate connection should be such that λ of component column i.e

$$\frac{c}{\gamma_{min,one}} \geq 50$$


$$\geq 0.7 \lambda_{whole value} = 0.7 \times 1.05 \lambda_0$$



$$\gamma_{min,one} = \gamma_{vv}$$



$$\gamma_{min,one} = \gamma_{yy}$$



$$\gamma_{min,one} = \gamma_{yy}$$


5) Effecting length of lacing bar

$$\lambda_{eff} = \lambda \quad (\text{for single lacing})$$

$$= 0.7 \lambda \quad (\text{for double lacing})$$


$$= 0.7 \lambda \quad \text{for welded lacing}$$

$\lambda \rightarrow$ Distance b/w inner bolts & welds.



⑥ Max. λ

for single lacing $\frac{\lambda_{eff}}{\gamma_{min}} \nless 145$



$$\gamma_{min} = \sqrt{\frac{I_{min}}{A}} = \sqrt{\frac{bt^3}{12bt}} = \frac{t}{\sqrt{12}}$$

⑦ Min. width of lacing flat

min width of lacing flat shall be 3 times of the Nominal dia of bolt.

⑧ Min. thickness of lacing bar

* $t_{min} = \frac{\lambda_{eff}}{40}$ → for single lacing


$= \frac{\lambda_{eff}}{60}$ → for Double lacing

⑨ Design force for lacing


lacing should be designed for T & C due to SF in column. There can be SF in column due to bending, lateral loading or accidental eccentricity or incidental eccentricity.

Due to incidental or * unavoidable eccentricity transverse SF is taken as 2.5% of factored axial load.

This shear is divided equally in all parallel planes resisting the shear.





$$SF = V = \frac{2.5}{100} P_u, \text{ when axial load only}$$





$$SF = V = \frac{M_y}{l} \quad \text{when moment only}$$

$$SF = V = \frac{2.5 P_y}{100} + \frac{M_y}{l} \quad \text{when axial force and moment both}$$



⑩ Tension & comp. in lacing due to shear.




$$F \sin \theta = V/2$$

$$F = \frac{V}{2 \sin \theta}$$

if @ a joint 2-lacing bars are meeting, one of them will be in tension and other will be in compo.

(11) check for safety for lacing Bar

A) When in Tension



$$F \leq \frac{0.9 f_u}{\gamma_{m1}} \cdot (b - d_o) t$$


B) When in Compression

$$F \leq A_e \cdot f_{cd}$$

$$\lambda = \frac{l_{eff}}{r_{min}} = \frac{l_{eff}}{t / \sqrt{12}}$$


calculate f_{cd} based on λ
considering buckling class C (solid sec)

(12) Design for connection



single lacing non-intersecting, bolt shall be designed for force F

$$\text{no. of bolts} = \frac{F}{V_{db}}$$



$$\begin{aligned}\text{Net force} &= 2F \cos \theta \\ &= 2 \frac{V}{2 \sin \theta} \cos \theta \\ &= V \cot \theta\end{aligned}$$

$$\text{no. of bolts} = \frac{V \cot \theta}{V_{db}}$$

The bolts will be in single shear for the resultant force and for the individual force also.

$$V \cot \theta > \frac{V}{2 \sin \theta}$$


$$\frac{V \cos \theta}{\sin \theta} > \frac{V}{2 \sin \theta}$$

$$\cos \theta > \frac{1}{2} \Rightarrow \theta < 60^\circ$$

$$\left\{ \begin{array}{l} \text{When } \theta < 60^\circ \Rightarrow n = \frac{V \cot \theta}{V_{db}} \quad \{ \text{for resultant} \} \\ \text{When } \theta > 60^\circ \Rightarrow n = \frac{V}{2 \sin \theta V_{db}} \quad \{ \text{for single force} \} \end{array} \right.$$

At the top & bottom of laced column, we need to provide end batten and recommendation will be covered in Batten column.

Battered column



Design recommendation

- ① no. of batten shall be such that column is divided into not less than 3 parts longitudinally i.e. min. no. of intermediate battens should be 2
- ② λ of batten column

λ shall be taken as $1.1 \lambda_0$

- ③ check for local buckling of component column


$$\frac{C}{\gamma_{min, one}} \geq 50 \quad \checkmark$$
$$\geq 0.7 \lambda_{whole column}$$

④ Width of batten

A) For intermediate Batten

The intermediate batten shall have an effective depth of not less than $\frac{3}{4}$ x perpendicular distance b/w the centroid of main member.

but in no case it shall be less than $2 \times$ width of one member in the plane of batten.



$$d_i \nless 2b$$

$$d_i \nless \frac{3}{4} (s + 2C_{yy})$$

$$D_i = d_i + 2e$$

B) For end batten

$$d_e \nless 2b$$

$$d_e \nless s + 2C_{yy}$$


$$D_e = d_e + 2e$$

$e \rightarrow$ edge distance.

⑤ Thickness of batten






$$\text{shall be } < \frac{l}{50} \quad \checkmark$$

$l \rightarrow$ Distance b/w inner most connecting line of bolt or weld.



⑥ Shear due to accidental eccentricity shall be taken as 2.5% of the axial loading and this shear shall be divided equally b/w parallel planes resisting the shear if there is lateral loading or moment acting on the column, shear will be calculated due to these also.

⑦ Batten plate shall be designed for BM and SF due to transverse shear.



The Batten plate shall be designed for $BM = \frac{V_c}{4}$
and $sf = \frac{V_c}{2l}$


$$M_{max} = \frac{f_y}{\gamma_{mo}} \times \frac{t D^2}{6}$$

$$V_{max} = \frac{f_y}{\sqrt{3} \gamma_{mo}} t D$$

The above check shall be done for intermediate Batten and if intermediate Batten is safe then end batten will be safe.

Design for connection

The connection shall be designed as eccentric connection subjected to direct shear V_{max} and twisting moment M_{max}



$$F_{Ri} = \sqrt{F_{Di}^2 + F_{Ti}^2 + 2 F_{Di} F_{Ti} \cos \theta}$$

For safety $F_{Ri} < V_{db}$ (Bolt value)

Ex. Design a Built up column to carry an axial load of 700 kN use 2 channel back to back $l_{eff} = 10$ m, provide single lacing with bolted connection. adopt grade of steel Fe 410, M20 Bolt, 4.6

available channel Sec^r are -

ISM C 300

$$A = 4564 \text{ mm}^2$$

$$r_{xx} = 118.1 \text{ mm}$$

$$r_{yy} = 26.18 \text{ mm}$$

$$C_{yy} = 23.6 \text{ mm}$$

$$b = 90 \text{ mm}$$

$$g = 50 \text{ mm}$$

ISM C 350

$$A = 5366 \text{ mm}^2$$

$$r_{xx} = 136.6 \text{ mm}$$

$$r_{yy} = 28.3 \text{ mm}$$

$$C_{yy} = 24.4 \text{ mm}$$

$$b = 100 \text{ mm}$$

$$g = 60 \text{ mm}$$

$f_y = 250 \text{ MPa}$, Buckling class $\rightarrow C$

λ $f_{cd} \text{ (MPa)}$

50 183

60 168

70 152

80 136

90 121

100 107


110 94.6

120 83.7

130 ~~59.2~~ 74.2

$$f_u = 1.5 \times 700 = 1050 \text{ kN}$$

consider 2-ISM C 300 back-back



$$\lambda_{max} = \frac{l_{eff}}{r_{min}}$$

$$r_{yy} > r_{xx}$$

$$= \frac{l_{eff}}{r_{xx, com}}$$

$$r_{xx, com} = \sqrt{\frac{2 I_{xx, one}}{2 A_{one}}} = r_{xx, one}$$

$$\lambda_{max} = \frac{l_{eff}}{\gamma_{xx, one}} = \frac{10 \times 10^3}{118.1} = 84.67 < 180$$

O.K

for a laced column, $\lambda_{max} = 1.05 \lambda_o$

$$= 1.05 \times 84.67$$

$$= 88.91$$

$$f_{cd} = 136 + \frac{(121-136)}{(90-80)} (88.91-80)$$


$$f_{cd} = 122.63 \text{ MPa}$$

Axial load carrying capacity — $122.63 \times 2 \times 4564$

$$= 1119.4 \text{ kN} > 1050 \text{ kN}$$

O.K

Spacing b/w the channels. (S)



In order to make $\gamma_{yy} > \gamma_{xx}$ i.e. no buckling in lacing plane we need to ensure —

$$I_{yy, comb} > I_{xx, comb}$$

$$= \frac{2 \times \left[I_{yy, one} + A_{one} \left(l_{yy} + \frac{S}{2} \right)^2 \right]}{2 A_{one}} = \frac{2 \times I_{xx, one}}{2 A_{one}}$$


$$= \gamma_{yy, one}^2 + \left(l_{yy} + \frac{S}{2} \right)^2 = \gamma_{xx, one}^2$$

$$= 26.18 + \left(23.6 + \frac{S}{2} \right)^2 = 118.1$$

$$S = 183.12 \text{ mm}$$

let us provide spacing b/w channels $S = 200 \text{ mm}$

Lacing Design



$$S + 2g = 200 + 2 \times 50 = 300 \text{ mm.}$$

consider $\theta = 45^\circ$

$$l = \frac{300}{\frac{1}{\sqrt{2}}} = 424.26 \text{ mm.}$$

$$\text{thickness of lacing flat} = \frac{l_{\text{eff}}}{40} = \frac{424.26}{40} = 10.6 \text{ mm}$$

consider thickness = 12 mm

$$\begin{aligned} \text{width of lacing flat} &= 3d \\ &= 3 \times 20 = 60 \text{ mm.} \end{aligned}$$

$$b = 60 \text{ mm, } t = 12 \text{ mm}$$

check for buckling of component column

$$c = 2 \times (s + 2g) = 600 \text{ mm.}$$

$$\lambda_{\text{component, column}} = \frac{c}{r_{\text{min, one}}} = \frac{600}{26.18} = 22.91$$

$\nless 50$
 $\nless 0.7 \lambda_m$
 $\nless 0.7 \times 88.91$
 $\nless 62.23$
OK.

1 Check for buckling of lacing flat

$$\lambda_{\text{max}} = \frac{l}{r_{\text{min}}} = \frac{l}{t/\sqrt{12}} = \frac{424.26}{12/\sqrt{12}} = 122.47$$

$\nless 145$
 O.K

$$\text{Shear force} = \frac{2.5}{100} \times P_u = \frac{2.5}{100} \times 1050 = 26.25 \text{ kN.}$$

comp./tensile force on lacing flat

$$f = \frac{V}{2 \sin \theta} = \frac{26.25}{2 \sin 45^\circ} = 18.56 \text{ kN.}$$

check in comp.

f_{cd} in lacing flat for $\lambda = 122.47$

$$f_{cd} = 83.7 + \left(\frac{74.2 - 83.7}{130 - 120} \right) \times (122.47 - 120)$$

$$f_{cd} = 81.37 \text{ MPa.}$$

$$\begin{aligned} \text{force carrying capacity of lacing flat} &= f_{cd} A_e \\ &= 81.37 \times 12 \times 60 \\ &= 58.58 \text{ kN} \end{aligned}$$

$$18.56 \text{ kN}$$

Check in tension

$$\text{Net sec}^{\text{u}} \text{ Rupture strength} = \frac{0.9 f_y}{\gamma_{m1}} (B - d_o) t$$

$$= \frac{0.9 \times 410}{1.25} (60 - 22) \times 12$$

$$= 134.6 \text{ kN} > 18.56 \text{ kN}$$

$$\text{Gross sec}^{\text{u}} \text{ yielding} = \frac{f_y}{\gamma_{m0}} \times B \times t$$

$$= \frac{250}{1.1} \times 60 \times 12 = 163.63 > 18.56 \text{ kN}$$

OK.

Design of connection

for M20 bolt, $V_{db} = 45.27 \text{ kN}$

$$\theta = 45^\circ < 60^\circ$$

connection shall be design for a force of

$$V \cot \theta = 26.25 \times \cot 45 = 26.25 \text{ kN}$$

$$\text{No. of bolts} = \frac{26.25}{45.27} \approx 1 \text{ bolt}$$

Que Design the column given in previous Que. considering batten plate.

for batten column $\lambda_{in} \rightarrow 1.1 \lambda_0$

$$= 1.1 \times \frac{B_{\text{eff}}}{\gamma_{xx}}$$

$$= 1.1 \times \frac{10 \times 10^3}{118.1} = 93.14$$

$$f_{cd} = 121 + \frac{(107 - 121)}{100 - 90} \times (93.14 - 90)$$

$$f_{cd} = 116.6 \text{ MPa}$$

$$P_d = f_{cd} \times A_e = 116.6 \times 2 \times 4564 = 1064.32 \text{ kN}$$

> 1050 kN

O.K

consider $S = 200 \text{ mm}$.

Design of Batten

$$l = S + 2g$$

$$= 300 \text{ mm}$$

$$\text{thickness} = \frac{300}{50}$$

$$= 6 \text{ mm}$$

$$d_i \leq 2b = 2 \times 90 = 180 \text{ mm}$$

$$\leq \frac{3}{4}(S + 2g)$$

$$= \frac{3}{4}(200 + 2 \times 23.6)$$

$$= 185.4 \text{ mm}$$

$$D_i = d_i + 2e$$


$$= 186 + 2 \times 1.5 \times 22 = 252 \text{ mm}$$

$$D_e \leq 2b = 180$$

$$\leq S + 2g = 247.2 = 247.2 \text{ mm}$$

$$D_e = 247.2 + 2 \times 1.5 \times 22 = 313.2 \text{ mm}$$

$$D_e = 315 \text{ mm}$$



check for buckling of component column

$$\frac{C}{\gamma_{min, one}} \geq 50$$

$$\geq 0.7 \times \lambda_{whole} = 0.7 \times 93.14 = 65.2$$

$$C \geq 50 \times \gamma_{min, one} = 50 \times 26.18$$

$$= 1309 \text{ mm}$$

take $c = 1200 \text{ mm}$.

$$\text{BM, } M_{\max} = \frac{VL}{4} = \frac{26.25 \times 1.2}{4} = 7.87 \text{ kNm}$$


$$\text{SF, } V_{\max} = \frac{VL}{2l} = \frac{26.25 \times 1.2}{2 \times 0.3} = 52.5 \text{ kN}$$

moment capacity of intermediate Batten

$$\begin{aligned} &= \frac{f_y}{\gamma_{mo}} \times \frac{tD^2}{6} = \frac{250}{1.1} \times \frac{6 \times 252^2}{6} \\ &= 14.43 \text{ kNm} > 7.87 \text{ kNm} \\ &\quad \underline{\underline{0.k.}} \end{aligned}$$

$$\text{Shear capacity} = \frac{f_y}{\sqrt{3} \gamma_{mo}} tD$$

$$\begin{aligned} &= \frac{250}{\sqrt{3} \times 1.1} \times 6 \times 252 = 198.63 \text{ kN} \\ &> 52.5 \text{ kN.} \\ &\quad \underline{\underline{0.k.}} \end{aligned}$$






$$n = \sqrt{\frac{6M}{m p V_{db}}}$$

$$f_{Di} = \frac{V}{n}$$

$$f_{Ti} = \frac{T r_i}{A_i}$$

connection can be designed as eccentric connection for a single line of bolt.

Column Bases




If steel column is directly placed on a concrete pedestal, concrete will crush, to safeguard against this, the area of load transfer needs to be increased. The max. pressure on concrete $<$ the permissible bearing stress in concrete in compression.


• To increase the area of load transfer, we provide base plate below the column. The arrangement used to transfer the column load to ground is called column Base and generally 3 types of column Bases are used.


- i) Slab base
- ii) Gusseted base
- iii) Grillage foundation

① Slab Base



③ Grillage Foundation






- *
 → slab base is generally used for axial loading
Gusseted base is used for Axial loading + moment
Grillage foundation is used when supporting soil is very weak and load is to be transferred @ a shallow depth. it is also used for temporary construction.

NOTE The beams in Grillage foundation shall be designed for BM + SF + Web crippling.

Slab Base

Case (i) When column is subjected to pure Axial loading.



$$\text{Base pressure} = \frac{P_u}{BL} = w$$

P_u → factored load

Generally for Axial loading max. comp. stress in concrete can be taken as $0.45 f_{ck}$

We can consider length Based on depth of column and nominal angle size,

Width of Base plate can be calculated from permissible stress criteria

- for purely axial loading in case of slab base we generally provide a nominal angle of $60 \times 60 \times 8$ mm.

$$L_{\min} = D + 2 \times 60 + 2 \times 5 \\ = D + 130 \text{ mm}$$


$$\frac{P_u}{L B} < 0.45 f_{ck}$$

The slab base will bend about secⁿ ①-① & secⁿ ②-②. Taking into account the poisson's effect the design moment $M = M_{11} - \mu M_{22}$

$$M_{11} = W \cdot \alpha \cdot l \cdot \frac{\alpha}{2} = \frac{W \alpha^2}{2}$$

$$M_{22} = W \beta \cdot 1 \cdot \frac{\beta}{2} = \frac{W \beta^2}{2}$$

$$\Rightarrow M = \frac{W \alpha^2}{2} - \mu \frac{W \beta^2}{2}$$



$$M \text{ for } 1 \text{ mm strip} \\ = 1.2 \frac{f_y}{\gamma_{m0}} \times \frac{1 \times t^2}{6}$$

$$\Rightarrow \frac{1.2 f_y}{\gamma_{m0}} \times \frac{t^2}{6} > \frac{W \alpha^2}{2} - \mu \frac{W \beta^2}{2}$$

$$t \geq \sqrt{\frac{2.5 W (\alpha^2 - \mu \beta^2)}{f_y / \gamma_{m0}}}$$

$\mu = 0.3$
for elastic
zone.

The above expression is valid for uniform Base pressure
As per IS code


$$t \geq \sqrt{\frac{2.5 W (\alpha^2 - 0.3 \beta^2)}{(f_y / \gamma_{m0})}}$$

also $t \geq t_f$



where α = larger overhang
 β = shorter overhang.

When base pressure is non-uniform, calculate M_{11} and M_{22}
 $M = M_{11} - \mu M_{22}$


Case II When Axial load + moment in the column



a) When $e \leq \frac{L}{6}$



The entire base will be subjected to comp stress.




for safety in bearing $\frac{P}{LB} \left(1 + \frac{e}{L}\right) \leq$

from above eqⁿ we can calculate B
(consider $L \geq 6e$)


As per IS code When Base pressure is Varying linearly, max. permissible Base pressure = $0.6 F_{uc}$

As the Base is in comp we don't require to design Anchor bolt.

b) When $e > \frac{L}{6}$




in this case there will be tensile stress in some part of base plate



$$\Rightarrow \frac{1}{2} \cdot \sigma_{mod.} \cdot 3x \cdot B = P$$

$$x = \frac{L}{2} - e$$




In this case we need to also consider the tensile force of the anchor bolt and hence total force on the base will be force of the modified base pressure diagram - Tensile force on the bolt. However the x value of the base pressure diagram will change due to the tensile force.

The exact base pressure diagram can be obtained by trial & error procedure.

Que. Design a slab base for a column carrying an Axial force = 700 kN and BM = 60 kN.m
Grade of concrete in foundation $\rightarrow$ M30

column $\rightarrow$ ISMB 300, flange width = 140 mm

$P = 700$ kN, BM = 60 kNm, M30, ISMB 300
 $b_f = 140$ mm.




$$P_u = 1.5 \times 700 = 1050 \text{ kN}$$

$$M_u = 60 \text{ kNm} \times 1.5 = 90 \text{ kNm}$$

$$e = \frac{M_u}{P_u} = \frac{90 \times 10^3}{1050} = 85.71 \text{ mm}$$

$$\text{length of base plate } L \geq 6e \geq 6 \times 85.71 \geq 514.28 \text{ mm}$$



$$L_{\min} = 300 + 2 \times 60 + 2 \times 5 = 430 \text{ mm}$$

Assume $L = 600$ mm.


$$\Rightarrow \frac{P_u}{LB} \left(1 + \frac{6e}{L} \right) \leq 0.6 f_{uc}$$

$$\frac{1050 \times 10^3}{600 \times B} \left(1 + \frac{6 \times 85.71}{600} \right) \leq 0.6 \times 30$$

$$B \geq 180.5 \text{ mm}$$


Take $B = 200 \text{ mm}$.

Dimensions of base plate $L \times B = 600 \times 200 \text{ mm}$.



$$\sigma_{\max} = \frac{P_u}{LB} \left(1 + \frac{6e}{L} \right) = 16.25 \text{ MPa}$$


$$\sigma_{\min} = \frac{P_u}{LB} \left(1 - \frac{6e}{L} \right) = 1.25 \text{ MPa}$$



$$M = M_{11} - \mu M_{22}$$

$$\sigma_3 = 1.25 + \frac{(16.25 - 1.25)}{600} \times 450$$

$$\sigma_3 = 12.5 \text{ MPa}$$



$$M_{11} = 0.5 (16.25 + 12.50) \times 150 \times \left(\frac{150}{3} \left(\frac{2 \times 16.25}{16.25 + 12.50} + 12.50 \right) \right)$$

$$M_{11} = 0.16875 \text{ kNm.}$$

$$M_{22} = 12.5 \times 30 \times \frac{30}{2} = 0.005625 \text{ kNm.}$$

$$M = M_{11} - \mu M_{22}$$



$$1.2 \times \frac{1 \times t^2}{6} \times \frac{f_y}{\gamma_{mo}} \geq (0.16875 - 0.3 \times 0.005625) \times 10^6$$

$$\Rightarrow t \geq 60.60 \text{ mm.}$$

provide $t = 65 \text{ mm.}$

Also $t_{\text{provided}} > t_f$

Column splices



① We need to connect 2-Column due to limited available length

② change in c/s due to decrease in load

The ideal location of column splice is @ a height of

* $\frac{R}{4}$ from Top or bottom of column.
* $h \rightarrow$ floor height

case-(i) When the higher story column flange rest completely on the lower story column flange,

Then we consider 2-cases —

a) column ends are milled (smooth/machine finish)

B) column ends are not milled.

When column ends are milled, all the direct load will be assumed to be transferred to lower story column flange through Direct bearing. and in this case splice plates are designed simply to keep the 2-column in position.

However in general we design splice plates for 50% of the applied load. i.e. $\frac{P}{4}$ for each splice plate (NOT a codal criteria)

for a column with P & M

design splice for $\rightarrow \frac{M}{4}$. When milled (as per code)

Design splice for $\rightarrow \frac{P}{4} + \frac{M}{4}$ } When milled
 $\frac{P}{4} - \frac{M}{4}$ } (general practice)

Case (ii) When column ends are not milled we need to design the splice for entire axial load i.e. for each splice load will be $\frac{P}{2}$

In case of column carrying moment, splice plate may be subjected to tensile force, when $\frac{P}{2} - \frac{M}{l} < 0$


(Not milled)

In this case splice plate shall be designed as a tension splice

Once the design force is calculated, width of splice plate shall be taken as the width of column flange and for calculation of thickness we can assume-

$$f_{cd} = \frac{f_y}{\gamma_{mo}}$$

because due to very small length and intermediate bolts, buckling of splice plate won't be considered.



Design force in the splice

$$\frac{f_y}{\gamma_{mo}} = b_f \times t$$



$t \rightarrow$ thickness of splice plate

- Connection shall be designed for the obtained force considering bolt in single shear.

- if the higher story column flange < ^{lower}~~bottom~~ story column flange, width of the splice plate = width of ~~bottom~~ story column flange.


However we need to taper the splice plate to match the width of the higher story column flange (fig. 1)

In case of diffⁿ column size, if full bearing is available on the bottom story column then we may need a packing plate for splicing (fig. 2)



case-(ii)

In case the upper story column bears partially on the lower story column, then we need to design each spliced plate for a force of $P/2$ i.e. all loads are assumed to be transferred through splice plates only.






case-(iii)

When the top story column flange is not resting on bottom story column flange we need to provide a base plate on the top of the bottom story column and on these plates the column shall be placed.

length + width of base plate shall be same as column size (Bottom story)

The Design shall be done as follows :-







$$M_{\max} \leq \frac{f_y}{\gamma_{mo}} \frac{b_f t^2}{6}$$

NOTE

It is generally assumed that axial load is transferred by flange only and the lateral load / shear is taken care by Web.

If the column is also experiencing shear we need to provide shear splice in the Web / WRB splice.



Shear at the net secⁿ

$$\frac{1.5 V}{(1-2d_o) 2t} \leq \frac{0.9 f_u}{\sqrt{3} \gamma_{m1}}$$

Shear @ the gross secⁿ

$$\frac{1.5 V}{2t \cdot l} \leq \frac{f_y}{\sqrt{3} \gamma_{m0}}$$

1.5 factor is to consider the max. shear stress

Ques. A column secⁿ ISMB 300 is to be sliced
consider column ends to be machined for
complete bearing, grade Fe 410, $P_u = 450 \text{ kN}$
 $M_u = 30 \text{ kNm}$, $V_u = 90 \text{ kN}$

Design the splice plate & Bolted connection
($b_f = 250 \text{ mm}$) $t_w = 6 \text{ mm}$, $t_f = 10.6 \text{ mm}$.
root radius $r_1 = 11 \text{ mm}$

Assuming 50% of P_u to be transferred through
splices, Direct load on each splice = $\frac{P_u}{4} = \frac{450}{4} = 112.5 \text{ kN}$

load on each splice due to applied moment
 $= \frac{30 \times 10^3}{300} = 100 \text{ kN}$

so force on splices = $112.5 + 100 = 212.5 \text{ kN}$ (C)
 $112.5 - 100 = 12.5 \text{ kN}$ (C)

thickness of splice plate $\frac{212.5 \times 10^3}{b_f \left(\frac{f_y}{\gamma_{m1}} \right)} = 3.74 \text{ mm}$

consider (provide) thickness of splice plate = 6 mm
 Assume M20, 4.6

$$V_{dsp} = 45.27 \text{ kN}$$


$$V_{dpb} = \frac{2.5 \times K_b \times d + f_u}{\gamma_{mb}} = \frac{2.5 \times 0.5 \times 20 \times 6 \times 410}{1.25}$$

$$V_{dpb} = 49.2 \text{ kN}$$

$$V_{db} = \underline{\underline{45.27 \text{ kN}}}$$

$$\text{No. of bolts} = \frac{212.5}{45.27} = 4.69$$

6 bolts



$$\begin{aligned} \text{length of splice plate} &= 2 \times (2e + 2p) \\ &= 2 \times (2 \times 1.5d_0 + 2 \times 2.5d) \\ &= 332 \text{ mm} \end{aligned}$$

provide $l = 332 \text{ mm}$

shear splice design

$$V_{dsb} = \frac{45.27}{0.78} \times 1.78 = 103.3 \text{ kN}$$

bolts are in double shear

$$V_{app} = \frac{2.5 K_b \times d \times t \times f_u}{\gamma_{mb}} = \frac{2.5 \times 0.5 \times 20 \times 6 \times 410}{1.25}$$

$$= 49.2 \text{ kN}$$

$$V_{ab} = 49.2 \text{ kN}$$

$$\Rightarrow \text{No. of bolts req.} = \frac{90}{49.2} = 1.83$$

provide 2 bolts.

Net secⁿ

$$\frac{1.5 V_u}{(l_s - 2d_o) 2t} \leq \frac{0.9 f_u}{\sqrt{3} \gamma_m}$$

$\downarrow$ $\downarrow$
 22 6

$$\Rightarrow l_s \geq 110 \text{ mm}$$

provide width of splice plate = 110 mm.

To accommodate 2 bolts min. width req. is $p+2e$
 $= 116 \text{ mm}$

hence provide $\rightarrow 120 \text{ mm}$

$$\text{length of splice plate} = 4e$$

$$= 132 \text{ mm}$$

Provide = 140 mm.

BEAMS

Joists

closely spaced beams to support roof

Girder

A large beam supporting a no. of joists.

purlin


Beams provided over truss to support roof.

Girt

Horizontal beams spanning the wall column of industrial buildings to support wall coverage.

Costellated Beams

Beams with opening in b/w, Higher MOI low Axial load capacity.





Beam can have lateral buckling of comp. flange on account of bending comp.

Lateral buckling of comp. flange causes instability in beam also leads to torsional moment. This buckling is also called as lateral torsional buckling

To avoid lateral torsional buckling we need to support comp. flange of beam and it can be done by providing cross beams, making the comp. flange heavier or by inserting the comp. flange into concrete slab also we can provide shear connectors in the comp. flange.


This type of beam which are laterally stable can be called as laterally restrained beams.



As per IS code full lateral restraint to comp. Flange may be assumed to exist. if the frictional or other Positive restraint (Sagging moment) of a floor connection to the comp. flange of the member is capable of resisting lateral force $\geq \underline{2.5\% \text{ of the Max. force in the comp. Flange of the beam.}}$

Classification of section sections can be plastic, compact, semi-compact or slender (as discussed in previous chapter)

Bending strength of laterally restrained beams



$$\text{Design shear capacity} = \frac{f_y}{\sqrt{3} \gamma_{m0}} \cdot A_v$$

$A_v \rightarrow$ shear Area

Before finding out the Bending strength, we need to investigate whether the secⁿ is under High shear case or low shear case.

Design strength of Web in shear

shear is always assumed to resisted by web only



$$\text{Design shear capacity } V_d = \frac{f_y}{\sqrt{3} \gamma_{m0}} \cdot A_v$$

i) for Rolled secⁿ $A_v = D t_w$

ii) for Welded secⁿ $A_v = d t_w$


iii) for Built up secⁿ

$$A_v = d t_w$$



- for safety in shear, Max. factored SF i.e. $V_{u,max} \leq V_d$
- If Max. applied factored SF in Beam is $< 0.6 V_d$ then it is called low shear case. and if $V_{u,max} \geq 0.6 V_d$ then high shear case.

Moment capacity of secⁿ is independent of shear for low shear case. However under high shear case moment capacity of secⁿ gets reduced.* (web is not considered)
The interaction diagram b/w moment capacity and shear is shown below.



$M_d \rightarrow$ Design moment capacity of secⁿ (F+W)

$M_{Fd} \rightarrow$ moment capacity of Flange only

$V_d \rightarrow$ Design shear capacity

Moment capacity of secⁿ
(case-i) low shear case $\{ V_{u,max} < 0.6 V_d \}$

$$M_d = \beta \frac{f_y}{\gamma_{m0}} \cdot Z_p$$

$\beta = 1$ for plastic & compact secⁿ, Because

~~these~~ these secⁿ can go upto M_p

$\beta = \frac{Z_e}{Z_p}$, for semi-compact secⁿ, Because

this secⁿ can develop M_y only

Also $M_d \leq 1.2 \frac{f_y}{\gamma_{mo}} Z_e \longrightarrow \text{for S.S Beams} \quad \text{--- (1)}$

$M_d \leq 1.5 \frac{f_y}{\gamma_{mo}} \cdot Z_e \longrightarrow \text{for Cantilever Beams} \quad \text{--- (2)}$

① & ② checks are provided to prevent the onset of plasticity under working load.

Case-(ii) High shear case $\{ V_{u, \max} \geq 0.6 V_d \}$

In this case moment capacity of secⁿ will be less than full moment capacity because the complete web can't be taken to be eff. in resisting the moment. In this case moment capacity of plastic and compact secⁿ is calculated as M_{dv}

$$M_{dv} = M_d - \beta (M_d - M_{fd})$$

$$\beta = \left(2 \frac{V_u}{V_d} - 1 \right)^2$$

$$M_{dv} \leq 1.2 \frac{f_y}{\gamma_{mo}} \cdot Z_e$$

$M_d \rightarrow$ plastic design moment of secⁿ disregarding high shear effect i.e for low shear case


$$M_d = \frac{f_y}{\gamma_{mo}} Z_p \text{ for plastic and compact sec}^n$$

$M_{fd} =$ plastic design strength of Area of the C/s excluding the shear Area.

$V_u \rightarrow$ applied SF

$V_d \rightarrow$ shear strength (Design) as governed by Web Yielding or Web buckling.

* Shear में $\sqrt{3}$ नहीं




$$M_{fd} = M_d - \frac{f_y}{\gamma_{mo}} \left(\frac{t_w D^2}{4} \right) z_p$$

NOTE For semi-compact secⁿ even in case of high shear, M_d will be taken as $\frac{f_y}{\gamma_{mo}} \cdot Z_e$

check for deflection

- calculation of max. deflection can be done using service load, because deflection is a serviceability criteria
- The max. permissible limit for deflection is given in IS code, however under general cond. * We'll assume max. permissible deflection to be $\frac{\text{span}}{300}$

check for Web buckling



Web buckling occurs due to heavy point load and diagonal comp. in the web.

A) For low shear case

- * (i) When $\frac{d}{t_w} \leq 67 \epsilon$, no need to check for web buckling. *

$$\frac{\sqrt{2} d}{2} = l_{eff} = \frac{d}{\sqrt{2}}$$


$$\epsilon = \sqrt{\frac{250}{f_y}}$$

(ii) $\frac{d_1}{t_w} > 67 \epsilon$, check for Web buckling.

B) For High shear case

Always check for Web buckling.

To check for Web buckling Web shall be treated as a column of $\lambda = 2.5 \frac{d_1}{t_w}$





f_{cd} shall be calculated based on flexural buckling Using the λ obtained. and considering buckling class C

At load point $f_{cd} B_1 t_w \geq P$

At support $f_{cd} B_2 t_w \geq R$

Web crippling / crimpling





At Load Point $\frac{P}{B_1 t_w} \leq \frac{f_y}{\gamma_{m0}}$

At support $\frac{R}{B_2 t_w} \leq \frac{f_y}{\gamma_{m0}}$

- Beams may be subjected to web crippling due to heavy point load
- To check for web crippling we need to ensure that the bearing stress at the root of fillet $< \frac{f_y}{\gamma_{m0}}$

NOTE Generally if the ~~web~~ Beam is safe in web crippling then it will be safe in web buckling.

~~check~~ Steps for Beam Design

- 1) Shear
 - 2) Moment
 - 3) Deflection
 - 4) Buckling
 - 5) Crippling
 - 6) Local Buckling of W and F (Like plastic, compact sec_{er})
- 4, 5, 6 → are called secondary checks
1, 2, 3 → are called primary checks.


Rolled secⁿ are generally safe in secondary failure.

Design procedure for Rolled section

- ① calculate factored load, Max BM and SF
- ② calculate Z_p required using formula $Z_p = \frac{M_u}{f_y / \gamma_{m0}}$
- ③ consider the secⁿ based on Z_p required.
Given in IS 800:2007
- ④ classify the secⁿ as plastic compact / semi-compact
- ⑤ calculate Design shear strength (V_d)
- ⑥ ensure $V_{u, \max} \leq V_d$
check for low / high shear case
- ⑦ find out moment capacity of secⁿ based on classification of secⁿ & low / High shear case
- ⑧ check for Deflection.
- ⑨ check for Web buckling in case of $\frac{d}{t_w} > 67 \epsilon$
or high shear case
- ⑩ check for Web crippling.

Que. Determine the Bending strength of ISB 350
Considering the beam to be laterally supported
Assume low shear case and take Fe 410
properties:-

$$\begin{aligned} D &= 350 \text{ mm} & b_f &= 165 \text{ mm} \\ t_f &= 11.4 \text{ mm} & t_w &= 7.4 \text{ mm} \\ Z_e &= 751.9 \text{ cm}^3 & Z_p &= 851.11 \text{ cm}^3 \end{aligned}$$



$$\text{Fe 410} \quad f_y = 250 \text{ MPa} \quad \epsilon = \sqrt{\frac{250}{f_y}} = 1$$

$$M_d = \frac{\beta f_y}{\gamma_{m0}} \cdot Z_p$$

$$\frac{b_f}{2} = \frac{165}{2} = 82.5 \text{ mm}$$

$$\frac{b}{t_f} = \frac{82.5}{11.4} = 7.23 < 9.4 \epsilon \quad \uparrow 1$$

Section is plastic secⁿ

$$M_d = \beta \frac{f_y}{\gamma_{m0}} \cdot Z_p = \frac{1 \times 250}{1.1} \times 851.11 \times 10^3$$

$$M_d = 193.43 \text{ kNm}$$

$$\text{However, } M_d \nless \frac{1.2 f_y}{\gamma_{m0}} \times Z_e = \frac{1.2 \times 250}{1.1} \times 751.9 \times 10^3$$

$$M_d = 193.43 \text{ kNm}$$

Que A simple supported beam has eff. span of 4m. it carries a UDL of 10 kN/m including self wt. Design appropriate secⁿ using Fe 410, available secⁿ are as follows -

ISLB 200

D = 200 mm

b_f = 100 mm

t_f = 7.3 mm

t_w = 5.4 mm

Z_e = 169.7 cm³

Z_p = 184.34 cm³

γ₁ = 9.5 mm

Shape factor = 1.086

ISMB 150

D = 150 mm

b_f = 80 mm

t_f = 7.6 mm

t_w = 4.8 mm

Z_e = 96.9 cm³

Z_p = 110.48 cm³

γ₁ = 9 mm

1.140

ISMB 200

D = 200 mm

b_f = 100 mm

t_f = 7.8 mm

t_w = 5.7 mm

Z_e = 223.5 cm³

Z_p = 253.86 cm³

γ₁ = 11 mm

1.135

$$\text{factored load} = 1.5 \times 10 = 15 \text{ kN/m}$$

$$BM_{\max} = \frac{wL^2}{8} = \frac{15 \times 4^2}{8} = 30 \text{ kNm}$$

$$V_{u,\max} = \frac{wL}{2} = \frac{15 \times 4}{2} = 30 \text{ kN}$$

$$Z_{p \text{ req.}} = \frac{M_u}{f_y / \gamma_{mo}} = \frac{30 \times 10^6}{250 / 1.1} = 132 \text{ cm}^3$$

Consider ISLB 200

$$\frac{b_f}{2t_f} = \frac{100}{2 \times 7.3} = 6.8 < 9.4 \epsilon$$

$$\frac{d_1}{t_w} = \frac{D - 2t_f - 2r_1}{t_w} = \frac{200 - 2(7.3 + 9.5)}{5.4}$$

$$= 30.8 < 84 \epsilon$$

The secⁿ shall be considered as a plastic secⁿ
consider secⁿ is safe in bending.

$$V_d = \frac{f_y}{\sqrt{3} \gamma_m} \cdot A_v = \frac{250}{\sqrt{3} \times 1.1} \cdot 200 \times 5.4 = 141.71 \text{ kN}$$

$> V_{u,\max}$

Safe in shear

$$0.6 V_d = 85.05 \text{ kN}$$

$$V_{u,\max} < 0.6 V_d$$

~~safe~~ low shear case

check for Deflection

$$\delta_{\max} = \frac{5}{384} \frac{wL^4}{EI} = \frac{5}{384} \times \frac{10 \times (4 \times 10^3)^3}{2 \times 10^5 \times 169.7 \times 10^3 \times \frac{200}{2}}$$

$$= 9.821 \text{ mm.}$$

NOTE $\rightarrow d_1 \rightarrow$ Height of web having thickness t_w

$$\frac{J}{300} = \frac{4 \times 10^3}{300} = 13.33 \text{ mm} < 9.82 \text{ mm}$$


O.K

check for web buckling

$$\frac{d_1}{t_w} = \frac{166.4}{5.4} = 30.81 < 67 \varepsilon$$

O.K

check for web crippling



assume support width = 200 mm. (a)

$$= \frac{30 \times 10^3}{[a + 2.5(t_f + r_1)] t_w} = 122.96 \text{ MPa} > \frac{F_y}{\gamma_{m0}}$$

O.K

Que Design a laterally supported beam of $l_{eff} = 6 \text{ m}$ for following Data, ~~set~~ Fe 410, $M_u = 150 \text{ kNm}$, $V_u = 210 \text{ kN}$. Also check for web buckling and no need to check for crippling & deflection. Available secⁿ

~~ISLB~~ ISLB 325
 $D = 325 \text{ mm}$, $b_f = 165 \text{ mm}$
 $t_f = 9.8$, $t_w = 7 \text{ mm}$
 $r_1 = 16 \text{ mm}$, $Z_e = 607.7 \text{ cm}^3$
 $Z_p = 687.76 \text{ cm}^3$

ISLB 350
 $D = 350 \text{ mm}$, $b_f = 165 \text{ mm}$
 $t_f = 11.4 \text{ mm}$, $t_w = 7.4 \text{ mm}$
 $r_1 = 16 \text{ mm}$, $Z_e = 751.9 \text{ cm}^3$
 $Z_p = 851.1 \text{ cm}^3$

λ	100	110	120
f_{cd}	107	94.6	83.7

$$Z_{p, req.} = \frac{150 \times 10^6}{(250/1.1)} = \frac{M_u}{f_y / \gamma_{mo}}$$

$$= 660 \text{ cm}^3$$

Assuming above sec⁴ to be plastic or compact
Consider ISLB 325

$$\frac{b_f}{2t_f} = \frac{165}{2 \times 9.8} = 8.41 < 9.4 \epsilon$$

$$\frac{d_1}{t_w} = \frac{325 - 2(9.8 + 16)}{7} = \frac{273.4}{7} = 39.05 < 84 \epsilon$$

Hence plastic

$$V_d = \frac{f_y}{\sqrt{3} \gamma_{mo}} \times A_v = \frac{250}{\sqrt{3} \times 1.1} \times 2275$$

$$= 298.5 \text{ kN}$$

$$V_{u, max} > 0.6 V_d$$

$$210 > 0.6 \times 298.5$$

$$210 > 179.1 \text{ kN}$$

High shear case.

$$M_{dv} = M_d - \beta (M_d - M_{fd})$$

$$\beta = \left(\frac{2V_u}{V_d} - 1 \right)^2$$

$$\beta = \left(\frac{2 \times 210}{298.5} - 1 \right)^2 = 0.1656$$

$$M_d = \frac{f_y}{\gamma_{m0}} \times Z_p = \frac{250}{1.1} \times 687.76 = 156.3 \text{ kNm}$$

$$M_{Fd} = M_d - \frac{f_y \cdot t_w \cdot d^2}{\gamma_{m0} \cdot 4}$$

$$M_{Fd} = 156.3 - \frac{250}{1.1} \times \frac{7 \times 325^2}{4}$$

$$M_{Fd} = 114.29 \text{ kNm}$$


$$M_{dv} = 149.37 \text{ kN} \cdot \text{m} \approx 150 \text{ kN} \cdot \text{m}$$

O.K

check for Buckling

$$\lambda = 2.5 \frac{d_1}{t_w} = 97.625$$

consider $f_{cd} = 107 \text{ MPa}$.




$$\text{capacity} = 362.5 \times t_w \times 107$$

$$= 271.5 \text{ kN} > 210 \text{ kN}$$

Safe in Web buckling

Design procedure For built up Beams (Plated Beams)



plated Beams.





plate girder

$$A_p = \frac{Z_{p, req} - Z_{p, I sec}}{d}$$




$$\cancel{f_y} \cdot Z_p = \cancel{f_y} \frac{A_I}{2} \times y_I \times 2 + 2 \cancel{f_y} \cdot A_p \times y_p$$

$$A_p = \frac{Z_{p, req} - Z_{p, I sec}}{2 \times y_p} = \frac{Z_{p, req} - Z_{p, I sec}}{2 \times \left(\frac{d}{2} + \frac{t_p}{2} \right)}$$

$$A_p = \frac{Z_{p, req} - Z_{p, I sec}}{d}$$

- ② consider the plate dimⁿ and classify the secⁿ as plastic, compact or semi-compact
- ③ check for safety in shear & classify low/high shear case
- ④ find out the moment capacity based on secⁿ classification and ensure $m_u < M_{dv}$
- ⑤ check for Deflection, Web buckling, Web crippling.

Effect of Bolt holes



$$\frac{0.9 f_u}{\gamma_{m1}} A_n \geq \frac{f_y}{\gamma_{m0}} A_g$$

Effect of Bolt hole in Tension Flange need not be considered in Z_p if

$$\frac{0.9 f_u}{\gamma_{m1}} A_n \geq \frac{f_y}{\gamma_{m0}} A_g$$

i.e. gross secⁿ yielding governs the strength


$A_n \rightarrow$ net Area

$A_g \rightarrow$ gross Area of Tension flange upto root of fillet


if the above criteria is not satisfied, the eff. flange Area in Tension (A_{ef}) will be taken from the following eqⁿ -

$$0.9 \frac{f_u}{\gamma_{m1}} A_n = \frac{f_y}{\gamma_{m0}} A_{ef}$$

Shear lag effect



Shear lag effect of flange should be considered
When $b_o \leq \frac{l_o}{20}$, $b_i \leq \frac{l_o}{10}$



$l_o \rightarrow$ Distance b/w
points of O.B.M.

Que: Design a steel Beam secⁿ having
 $l_{eff} = 6.65$ m. it is supported @ ends with
end bearing of 150 mm. factored DL & LL are
63 kN/m. Total depth of Beam is restricted to
375 mm. Assume Beam to Beam laterally
supported, secⁿ available is ISWB 350

ISWB 350

$D = 350 \text{ mm}$, $b_f = 200 \text{ mm}$.

$t_f = 11.4 \text{ mm}$, $t_w = 8 \text{ mm}$.

$r_y = 12 \text{ mm}$, $Z_p = 995.49 \text{ cm}^3$, $Z_e = 887 \text{ cm}^3$

$W_u = 63 \text{ kN/m}$, $L = 6.65 \text{ m}$

$$M_u = \frac{W_u L^2}{8} = \frac{63 \times 6.65^2}{8} = 348.25 \text{ kNm}$$


$$V_u = \frac{W_u L}{2} = \frac{63 \times 6.65}{2} = 209.475 \text{ kN}$$

$$Z_{p, \text{req}} = \frac{M_u}{f_y / \gamma_{m0}} = \frac{348.25 \times 10^3}{250 / 1.1} = 1532.3 \text{ cm}^3$$

$$Z_{p, \text{available}} = 995.4$$

$$\text{Area of plate req} = \frac{Z_{p, \text{req}} - Z_{p, \text{available}}}{d}$$


$$= \frac{1532.3 - 995.4}{350 \times 10^{-1}} = 15.34 \text{ cm}^2$$



ISWB 350

consider plate of width 200mm and thickness 8 mm

$$A_{p, \text{provided}} = 200 \times 8 = 1600 \text{ mm}^2 > 1534 \text{ mm}^2$$



$$b_i \cong t_w + 2r_f + 2 \frac{d_o}{2}$$

$$= 8 + 2 \times 12 + 2 \times \frac{22}{2}$$

$$b_i = 54 \text{ mm.}$$

$$b_o = \frac{200 - 54}{2} = 73 \text{ mm.}$$

$$t_f = 11.4 \text{ mm.}$$

$$\frac{b_i}{t_f} = 6.75 < 29.3 \epsilon \Rightarrow \text{plastic}$$

$$\frac{b_o}{t_f} = \frac{73}{8} = 9.125 < 9.4 \epsilon \Rightarrow \text{plastic}$$

$$\frac{d_1}{t_w} = \frac{350 - 2(11.4 + 12)}{8} = 37.9 < 84 \epsilon \Rightarrow \text{plastic}$$

Section is plastic

hence adequate from bending moment capacity

$$V_d = \frac{f_y}{\sqrt{3} \gamma_{mo}} A_v = \frac{250}{\sqrt{3} \times 1.1} \times 350 \times 8 = 367.4 \text{ kN}$$

$$V_u = 209.47 \text{ kN}$$

$$V_{u, \max} < V_d \quad \text{safe in shear.}$$

$$V_u < 0.6 V_d$$

$$209.47 < 220.4 \text{ kN} \quad \text{low shear case.}$$

check for bolt holes A_{net}

consider M20, 4.6, 2 no. of bolts c/s.

$$A_{net} = (B - 2d_o) t \quad t = t_p + t_f$$
$$= (200 - 2 \times 44) \times 19.4 \quad = 8 + 11.4$$

$$A_{net} = 3026.4$$

$$A_g = B \cdot t$$
$$= 200 \times (8 + 11.4)$$

$$A_g = 3880$$

$$\frac{0.9 F_u}{\gamma_{m1}} A_{net} > \frac{F_y}{\gamma_{m0}} \times A_g$$

$$893.4 > 881.8 \text{ kN}$$

As the strength is governed by gross secⁿ yielding
No need to consider; reduction in Z_p due to bolt holes.

check for shear lag

$$\frac{l_o}{20} = \frac{6.65 \times 10^3}{20} = 332.5 \text{ mm} \quad \phi > 73 \text{ mm}$$

$$\frac{l_o}{10} = 665 \text{ mm} \quad \phi > 54 \text{ mm}$$